Graphical Digital Panel Meter [Tachometer/Speed Meter] Instruction manual

WPMZ-5-000-00-000



Watanabe Electric Industry Co., Ltd.

INTRODUCTION

Thank you for purchasing our graphical digital panel meter the WPMZ series.

This manual describes the functions, instructions on installing and wiring, operations etc.

Before using this product, please read this manual carefully and use the product correctly.

The latest manual can be downloaded as a file from our web site (<u>http://www.watanabe-electric.co.jp/en/</u>).

The file is in the PDF format and has the bookmark function for your convenience.

SUPPLIED ITEMS

Check that all the following items have been included in the delivered package.

item name		Quantity
Graphical pa	inel meter WPMZ (body)	1
Case fixing a	ttachment	2
Terminal blo	ck cover	1 (For supply power terminal)
	1 input / no output model	2 (7P×1, 13P×1)
Attached connectors	1 input / with output model	3 (7P×2, 13P×1) * Not BCD output 3 (7P×1, 13P×1, 34P×1) * BCD output
	2 inputs / no output model	3 (7P×2, 13P×1)
	2 inputs / with output model	4 (7P×3, 13P×1) * Not BCD output 4 (7P×2, 13P×1, 34P×1) * BCD output
Quick instruction manual		1

NOTES

•This manual is subject to change without notice for improvements of the product.

•Keep this manual with close reach of persons who use this product to provide for future use.

Table of contents

If you read this manual on a pc, you can jump to linked destination by clicking characters in blue.

1. PRECAUTIONS FOR USE	5
1-1. ENVIRONMENTS AND CONDITIONS OF USE	
1-2. INSTALLATION AND CONNECTION	5
1-3. CHECKING BEFORE USE	6
1 – 4. CHECKING FOR ABNORMALITIES	6
1-5. MAINTENANCE AND INSPECTION	6
1-6. DISPOSAL OF THIS PRODUCT	6
	-
2. WARRANTY	
2 – 1. TERM OF WARRANTY 2 – 2. WARRANTY RANGE	
2-3. LIMITATION OF LIABILITY	
3. BEFORE USING THE PRODUCT	8
3-1. MODEL CODES	8
4. MOUNTING METHOD	٥
4. MOONTING METHOD 4-1. EXTERNAL FORM DIMENSIONS	
4 – 2. PANEL MOUNTING METHOD	
5. CONNECTING TERMINALS	
5-1. WIRING TO TERMINALS	
5-1-1. CONNECTING TERMINALS	
5-1-2. WIRING TO SCREWLESS TERMINALS	
5-1-3. THE LOCATION OF EACH TERMINAL STAND	
5-2. CONNECTION FOR LOWER ROW TERMINALS	
5-2-1. COMPARETIVE OUTPUT/EXTERNAL CONTROL INPUT	
5-2-2. SUPPLY POWER	
5-3. CONNECTION FOR UPPER ROW TERMINALS	
5-3-2. LINE DRIVER INPUTS	
5-4-1. ANALOG OUTPUT	
5-4-2. BCD OUTPUT	
5-4-3. RS-232C	
5 4 5. KS 2320	
6. NAMES OF EACH PART	
6-1. NAMES OF EACH PART	
6-2. EXPLANATION OF ICONS	
6-2-1. DISPLAY ICONS ON THE MEASUREMENT WINDOW	
6-2-2. KEY OPERATION ICONS ON THE SETTING WINDOW	
7. MODES OF OPERATION	
7 – 1. WHAT YOU CAN DO USING THIS PRODUCT	
7-2. STATE TRANSITION DIAGRAM	
8. MEASUREMENT MODE	
8 – 1. WHAT YOU CAN DO IN MEASUREMENT MODE	
8 – 2. OPERATIONS IN MEASUREMENT MODE	
8-3-1. MEASUREMENT (NUMERICAL NUMBER) DISPLAY	
8-3-2. LEVEL DISPLAY (BAR GRAPH)	
8-3-3. TREND DISPLAY (LINE GRAPH)	

9.	SETTING MODE	
	9-1. WHAT YOU CAN DO IN "THE SETTING MODE"	
	9-1-1. WHAT YOU CAN DO IN "THE INPUT SETTING GROUP"	
	9-1-2. WHAT YOU CAN DO IN "THE OUTPUT SETTING GROUP"	24
	9-1-3. WHAT YOU CAN DO IN "THE DISPLAY SETTING GROUP"	24
	9-1-4. WHAT YOU CAN DO IN "THE SYSTEM SETTING GROUP"	25
	9-1-5. WHAT YOU CAN DO IN "THE DIAGNOSIS GROUP"	
	9-2. OPERATION IN SETTING MODE	
	9-2-1. TRANSFER BETWEEN SETTING GROUPS	
	9-2-2. OPRERATING PROCEDURE	
	9-3. OVERVIEW OF PARAMETERS AND INITIAL VALUES	
	9-3-1. INPUT SETTING GROUP OVERVIEW	
	9-3-2. OUTPUT SETTING GROUP OVERVIEW	
	9-3-3. DISPLAY SETTING GROUP OVERVIEW	
	9-3-4. SYSTEM SETTING GROUP OVERVIEW	
	9-3-5. DISGNOSIS OVERVIEW	35
	9-4. DETAILS OF INPUT SETTING GROUP	
	9-4-1. PULSE INPUT A / PULSE INPUT B (WPMZ-5-*P*)	
	9-4-2. LINE DRIVER INPUT A / LINE DRIVER INPUT B (WPMZ-5-*L*)	50
	9-4-3. 2-INPUT CALCULATION	61
	9-4-4. EXTERNAL CONTROL	68
	9-5. DETAIL OF OUTPUTSETTING GROUP	
	9-5-1. COMPARATIVE OUTPUT AL1 - 4	70
	9-5-2. ANALOG OUTPUT	82
	9-5-3. BCD OUTPUT	87
	9-5-4. RS-232C COMMUNICATION	
	9-5-5. MODBUS COMMUNICATION	
	9-6. DETAIL OF DISPLAY SETTING GROUP	
	9-6-1. DISPLAY SELECT	102
	9-6-2. LEVEL DISPLAY	107
	9-6-3. TREND DISPLAY	
	9-7. DETAIL OF SYSTEM SETTING GROUP	
	9-7-1. GENERAL	114
	9-7-2. INITIALIZATION	
	9-8. DETAIL OF INPUT-OUTPUT DIAGNOSIS GROUP	
	9-8-1. INPUT DIAGNOSIS	
	9-8-2. OUTPUT TEST	128
10). CONTROL FUNCTIONS	
	10-1. EXTERNALCONTROL FUNCTIONS	
	10-1-1. EXTERNAL CONTROL FUNCTION ICONS	
	10-1-2. TERMINAL CONTROL	
	10-1-3. COMPARATIVE OUTPUT RESET FUNCTION	
	10-1-4. MEASUREMENT INHIBIT FUNCTION	
	10-1-5. DISPLAY HOLD FUNCTION	
	10-1-6. MAXIMUM VALUE HOLD FUNCTION	
	10-1-7. MINIMUM VALUE HOLD FUNCTION	
	10-1-8. PATTERN SELECT FUNCTION	
	10-1-9. MONITOR CHANGE FUNCTION	
	10-1-10. TREND HOLD FUNCTION	
	10-2-2. FUNCTIONS CAN BE REGISTERED TO SHORTCUT	
	10-2-3. REGISTERING SHORTCUT FUNCTIONS	
	10-2-4. PERFORMING SHORTCUT FUNCTIONS	140
4.4	COMPARATIVE OUTPUT FUNCTION	1.44
	11 – 1. COMPARATIVE OUTPUT FUNCTION	
	11 - 1 - 1. SOURCE DISPLAYABLE VALUE FOR COMPARISON	
	III I I. SUDIUL DISFLATABLE VALUE FUR UUMPARISUN	

11-1-2. LEVEL JUDGEMENT	
11-1-3. ZONE JUDGEMENT	
12. OUTPUT FUNCTIONS	
12-1. ANALOG OUTPUT FUNCTION	
12-1-1. SOURCE DISPLAYABLE VALUE FOR OUTPUT	
12-1-2. ANALOG OUTPUT SCALING	
12-1-3. OUTPUT RANGE OF ANALOG OUTPUT	
12-2. BCD OUTPUT FUNCTION	
12-2-1. SOURCE DISPLAYABLE VALUE FOR OUTPUT	
12-2-2. DATA OUTPUT	
12-2-3. ENABLE	
12-3. RS-232C COMMUNICATION FUNCTION	
12-4. RS-485 (MODBUS RTU) COMMUNICATION FUNCTION	
13. ERROR MODE	
13-1. DISPLAY ON OCCURRENCE OF AN ERROR	
13-2. LIST OF ERROR CODES AND RECOVERY PROCEDURES	
14. SPECIFICATIONS	
14-1. BASIC SPECIFICATIONS	
14-2. INPUT SPECIFICATIONS	
14-2-1. PULSE INPUT	
14-2-2. LINE DRIVER INPUT	
14-3. OUTPUT SPECIFICATIONS	
15. TROUBLESHOOTING	
16. APPENDIX	
16-1. KEY OPERATION REFERENCE CHART	
16-2. SETTING VARIABLES	

1. PRECAUTIONS FOR USE

1-1. ENVIRONMENTS AND CONDITIONS OF USE

Please do not use the product under the following circumstances. It might cause malfunctions and shortening the life.

- 1) Ambient temperature of out of -5 to 50 $^{\circ}$ C
- 2) Ambient humidity of out of 35 to 85%, or freezing condensing
- 3) High dust or metallic powder level (Storing in a dust-proof chassis and a c
- (Storing in a dust-proof chassis and a countermeasure against heat dissipation are required.)
- 4) Environment of corrosive gas, salty air or oily smoke
- 5) Environment of much vibration or impact
- 6) Environment of rain or water drops (except the front panel)
- 7) Environment of strong electromagnetical field or much exogenous noise

RESTRICTION FOR USE


- Do not use this product as a part of equipment which aimed at life maintenance of human bodies.
- Please avoid usages of this product which bring physical accident or property damage when it breaks down.

We do not take any responsibility about the special damage, the indirect damage and the passivity damage that occurred due to this product under any circumstance.

1-2. INSTALLATION AND CONNECTION

- 1) Please read this manual carefully before setting and connecting, be performed by a person having a specialized technique.
- 2) The insulation class of this product is as shown by the figure below. Please confirm that the insulation class satisfies a use condition prior to setting.

ī



!	Operational Insula	tion	L
DC power	Comparative outputs, External control input Analog output, BCD output,RS-232C	s,	RS-485 Modbus RTU
1	Input chA	In	out chB

- 3) Do not wire the power supply line, input signal lines and output signal lines near noise sources or relay drive lines.
- 4) Bundling or containing in a same duct with lines including noises might cause malfunctions.
- 5) This product works functionally normally right after power activation, but requires 30 minutes' warming to satisfy all performance requirements.

- 1) This product is a precision measuring instrument. Please be careful not to add the strong shock to this product by falls and so on.
- 2) Paying attention to the circuit diagram, connect wires to this product carefully. An inappropriate connection may cause troubles of the product, a fire or an electric shock.
- 3) Please avoid live line works. It may cause an electric shock, troubles or a burnout of the product by the short circuit or a fire.
- 4) The FG terminal must be connected to ground. The grounding should be Class D grounding (previous class 3 grounding). An inappropriate grounding may cause malfunctions of the product.
- 5) Please use wire which has appropriate specifications. Inappropriate wire may cause a fire because of heat generation.
- 6) Please use crimp terminals which meet specifications of wire. Otherwise, it may cause breaking of wire, poor contact and may bring into a malfunction of the product, a breakdown, a burnout, or a fire.
- 7) After tightening screws, confirm that the screws do not loosen. A looseness of screws may cause a

malfunction of the product, a fire or an electric shock.

- 8) An excessive tightening of screws may damage terminals or screws. A poor tightening of screws may cause a malfunction of the product, a fire or an electric shock.
- 9) Attach a terminal block cover to the product. Otherwise it may cause an electric shock.
- 10) Never attempt to disassemble or modify this product. It may cause a breakdown, an electric shock or a fire.

1 - 3. CHECKING BEFORE USE

Please install this product under the environments and conditions of use which meet requirements. If you find any damage to the product by the transportation or any problem, please contact to your dealer or our company directly.

1-4. CHECKING FOR ABNORMALITIES

If you find strange sound, smell, smoke, heat from this product, shut down the power immediately. And check followings before considering a breakdown of the product.

- 1) Power is supplied correctly.
- 2) Wires are connected correctly.
- 3) Wires have no breaking.
- 4) Settings are configured correctly.

1-5. MAINTENANCE AND INSPECTION

For the stain on the surface of the product, wipe it off using soft cloth. For heavy stein, turning off the power, wipe off it using cloth wrung out of water. Do not use organic solvents such as benzene and thinner.

For a trouble-free and long use of this product, give inspections of followings periodically.

- 1) Whether the product has damage.
- 2) Whether the display has abnormality.
- 3) Whether the product give out strange sound, smell, heat.
- 4) Mounting and connections of terminals have no looseness, check under power off condition.

1-6. DISPOSAL OF THIS PRODUCT

When you dispose this product, treat as a general industrial waste.

2. WARRANTY

2-1. TERM OF WARRANTY

The term of a warranty of this product is one year after delivery.

2-2. WARRANTY RANGE

If any failures found to be the responsibility of our company occurs within the term of warranty, the product shall be offered a replacement or repaired by retuning to us at no cost.

However, in the case that the cause of the failure corresponds to the followings, it is excluded from the warranty range.

- 1) Failure caused by being used under inappropriate conditions, circumstances and handlings which are written in this manual.
- 2) Failure caused by unapproved modifications or repair of structure, performance and specifications etc. which are performed not by our company.
- 3) Failure caused not by this product.
- 4) Failure caused by reasons unpredictable by standards of science and technology at time of the shipment from our company.
- 5) Failure caused by any other reasons that are found not to be the responsibility of our company including natural disasters, human disasters and accidental forces.

In addition, this warranty is limited to this product as a component; any other damages provoked by failure or defect of this product are out of this warranty range.


2-3. LIMITATION OF LIABILITY

Our company is not responsible for any consequential damage caused by this product.

3. BEFORE USING THE PRODUCT

3-1. MODEL CODES

The model code of this product is shown as below. Check the product which has been delivered has a same model code you ordered.





(Note 1) Combination of 2 inputs The combination of a pulse input and a line driver input is NOT selectable. (WPMZ-5-*PL and WPMZ-5-*LP are NOT available.)


- (Note 2) Pulse input: Generic pulse input excluding Line driver input. Open collector (NPN/PNP), voltage pulse, totem pole (complementary output), Zero cross (AC signal), two-wire (proximity sensor etc.)
- (Note 3) Line driver input: Line driver pulse input. RS-422 compatible line driver input.

4. MOUNTING METHOD

4 – 1. EXTERNAL FORM DIMENSIONS









4-2. PANEL MOUNTING METHOD

Panel cut dimensions are as shown by the figure below.



- 1) Removal of case fixing attachments
- 2) Installment of case fixing attachments



CAUTION

 \circ Prior to the installation of this product please read "1-1. ENVIRONMENTS AND CONDITIONS OF USE" (page5).

 \circ In the case of installation or replacing of this product, please pay attention to the damage and accident by dropping.

 \circ In the case of some wires are connected, do not install or replacing this product. It may cause shock, damage ,fire etc.

5. CONNECTING TERMINALS

5-1. WIRING TO TERMINALS

The connections to this product are done by connecting wires to the screw terminal block (power supply) and screwless terminal blocks on the back side of the body. Show below for the method and precautions.


5 - 1 - 1. CONNECTING TERMINALS

Use crimp-type terminal lugs for M3 screws to connect the terminals.


- ① Loosen the screws of the terminal block.
 - In the case of R-type terminal lugs, remove the screw terminals from the terminal block.
- (2)Insert lugs under the washers of loosened screws and fasten the screws. (Recommended torque: $0.6 [N \cdot m]$)

5 - 1 - 2. WIRING TO SCREWLESS TERMINALS

- ① Pushing the wire release button with a flat-blade screwdriver, open the wire insert hole. (Flat-blade screwdriver : The point of a blade width 2.5mm)
- ② Wire is inserted in an expanded wire insertion hole and a flat-blade screwdriver is removed. (Suitable wire:AWG24 to 16)









Note: In this manual, "channel A", "channel B" may be abbreviated to "chA", "chB" (or "Ach", "Bch").

5-2. CONNECTION FOR LOWER ROW TERMINALS 5-2-1. COMPARETIVE OUTPUT/EXTERNAL CONTROL INPUT

[Opencollector output product]





No.	Name	Description
1	AL1 c	AL1 open-collector output (collector)
2	AL2 c	AL2 open-collector output (collector)
3	AL3 c	AL3 open-collector output (collector)
4	AL4 c	AL4 open-collector output (collector)
5 AL+COM e	Common terminal for PNP output (emitter)	
5	AL+COM e	(NPN output : no connection)
6	AL-COM e	Common terminal for NPN output (emitter)
		(PNP output : GND for PNP)
7,8	COM	Common terminal for external control inputs
9	1	External control input No.1
10	2	External control input No.2
11	3	External control input No.3
12	4	External control input No.4
13	5	External control input No.5


*1 "AL-COM e terminal" and "COM

terminal" is connected internally and same voltage level.

5 - 2 - 2. COMPARETIVE OUTPUT(relay)/EXTERNAL CONTROL INPUT

[Relay output product]

Screwless terminals




Suitable wire: AWG 24 to 16

No.	Name	Description
1	AL1	AL1 relay output
2	AL1·2 COM	Common terminal for outputs of AL1 and AL2
3	AL2	AL2 relay output
4	AL3	AL3 relay output
5	AL3•4 COM	Common terminal for outputs of AL3 and AL4
6	AL4	AL4 relay output
7	×	N.C. *1
8	COM	Common terminal for external control inputs
9	EXT CONTROL 1	External control input No.1
10	EXT CONTROL 2	External control input No.2
11	EXT CONTROL 3	External control input No.3
12	EXT CONTROL 4	External control input No.4
13	EXT CONTROL 5	External control input No.5

*1 Please do not wire to N.C. terminal.

5 - 2 - 3. SUPPLY POWER


Screw terminals



Terminal	Name	Description
P1	POWER (+)	Power source terminal (In case of DC power, +V)
P2	POWER (-)	Power source terminal (In case of DC Power, 0V)
P3	FG (NC)	FG terminal (DC power option: no connection (Non-usable for a relay terminal))

5-3. CONNECTION FOR UPPER ROW TERMINALS 5-3-1. PULSE INPUTS

Screwless terminals



•Channel A pulse input

terminal	name	descriptions
14	IN	ChA pulse input terminal
15,16	GND	ChA input ground terminal
17	+EXC	ChA sensor power output terminal (+)
18	-EXC	ChA sensor power output terminal (-)
19	NC	No connection
15	NO	*Non-usable for a relay terminal
20	NC	No connection
20	INC.	*Non-usable for a relay terminal


*1 "GND terminal" and "-EXC terminal" is connected internally and same voltage level.

•Channel B pulse input

terminal	name	descriptions
21	IN	ChB pulse input terminal
22,23	GND	ChB input ground terminal
24	+EXC	ChB sensor power output terminal (+)
25	-EXC	ChB sensor power output terminal (-)
26	NC	No connection
20	NC	*Non-usable for a relay terminal
27	NC	No connection
21	NC	*Non-usable for a relay terminal

*1 "GND terminal" and "-EXC terminal" is connected internally and same voltage level.


• Examples for Input connections



Graphical Digital Panel Meter WPMZ-5 INSTRUCTION MANUAL

5 - 3 - 2. LINE DRIVER INPUTS

Screwless terminals



•Channel A line driver input

terminal	name	description
14	LINE (+)	ChA line driver input terminal (+)
15	LINE (-)	ChA line driver input terminal (-)
16	GND	ChA input ground terminal (+)
17	+EXC	ChA sensor power output terminal (+)
18	-EXC	ChA sensor power output terminal (-)
19	NC	No connection *Non-usable for a relay terminal
20	NC	No connection *Non-usable for a relay terminal


*1 "GND terminal" and "-EXC terminal" is connected internally and same voltage level.

•Channel B line driver input

terminal	name	description
21	LINE (+)	ChB line driver input terminal (+)
22	LINE (-)	ChB line driver input terminal (-)
23	GND	ChB input ground terminal (+)
24	+EXC	ChB sensor power output terminal (+)
25	-EXC	ChB sensor power output terminal (-)
26	NC	No connection *Non-usable for a relay terminal
27	NC	No connection *Non-usable for a relay terminal


*1 "GND terminal" and "-EXC terminal" is connected internally and same voltage level.

• Examples for Input connections



5-4. CONNECTION FOR MIDDLE ROW TERMINALS (OUTPUT)

5 - 4 - 1. ANALOG OUTPUT



Suitable wire: AWG24 to 16


Screwless terminals

terminal	name	descriptions	
28	V.OUT	Analog voltage output terminal (+)	
29	V.COM Analog voltage output terminal (-)		
30	NC No connection *Non-usable for a relay terminal		
31	A.OUT	Analog current output terminal (+)	
32	A.COM	Analog current output terminal (-)	
33,34	NC	No connection *Non-usable for a relay terminal	

*1 "V.COM terminal" and "A.COM terminal" is connected internally and same voltage level.

5 - 4 - 2. BCD OUTPUT

Crimp connector




Suitable wire: AWG#28 flat cable(7/0.127mm)

terminal	name	description	
1 to 4	$10^{0}1-8$	Bit 1-8 of BCD 10 ⁰ digit output terminals	
5 to 8	1011-8	Bit 1-8 of BCD 10 ¹ digit output terminals	
9 to 12	$10^{2}1-8$	Bit 1-8 of BCD 10 ² digit output terminals	
13 to 16	$10^{3}1-8$	Bit 1-8 of BCD 10 ³ digit output terminals	
17 to 20	$10^{4}1-8$	Bit 1-8 of BCD 10 ⁴ digit output terminals	
21 to 24			
25	POL	BCD polarity output terminal	
26	OVER	BCD over output terminal	
27	PC	BCD synchronous signal output terminal	
28	ENABLE	BCD enable terminal By bringing to same voltage level of -D.COM or connecting to -D.COM, transistors of BCD outputs become OFF.	
29 to 32	-D.COM	Common terminal for BCD open collector NPN	
33,34	+D.COM	External power terminal for BCD open collector PNP	

5 - 4 - 3. RS-232C

Screwless terminals




Suitable wire: AWG24 to 16

terminal	name	description	
28	RXD	RXD receive data terminal	
29	TXD	transmit data terminal	
30	SG	common terminal for communication function	
31 to 34	NC	no connection *Non-usable for a relay terminal	

5 - 4 - 4. RS-485 MODBUS RTU


Screwless terminals



Suitable wire: AWG24 to 16

terminal	name	description	
28	+	Non-inverting signal	
29	-	Inverting signal	
30	SG	Signal ground	
31	+	Non-inverting signal	
32	-	Inverting signal	
00.04	34 TERM	Terminal resistance (120Ω) terminals	
33,34		* Short 33 and 34 to be enable the resistance.	

*1 "No.28 and No.31 terminal" and "No.29 and No.32 terminal" is connected internally and same voltage level at RS-485.



No.	Name	Function
1	Display title	Indicates contents of display
2	Comparison result	Lights when the result of comparative output is ON.
3	Key lock	Lights when the key lock is effective.
4	Pattern	Indicates pattern No. in use.
5	1st item display	Displays measured value of 1st item
6	FUNC key	Used for registering external control shortcut function.
\bigcirc	MENU key	Used for moving to setting window and returning measurement window.
8	Arrow keys	Used to move the cursor while setting and move other windows. *When the shortcut function is registered, the assigned function will be valid by holding down the arrow key (over 1 second).
9	ENTER key	Used to validate setting value.
10	DISP key	Used to switch measurement windows.
(11)	Display unit	Unit for 1st item display
12	External control	Lights when any of external control functions are valid
13	3rd item display	Displays measured value of 3rd item
14	2nd item display	Displays measured value of 2nd item
(15)	Comparison result	Lights when the result of comparative output is ON.
(16)	Judgement value	Shows value or area of comparison judgement

6 – 2. EXPLANATION OF ICONS 6 - 2 - 1. DISPLAY ICONS ON THE

MEASUREMENT WINDOW

These icons are displayed on the top or the bottom of the measurement window.

icon	meanings	
P5	Indicates pattern No. in use.	
Â	Indicates key lock function is effective.	
Θ	Indicates comparative output reset function (an external control function) is effective.	
Ø	Indicates measurement inhibit function (an external control function) is effective.	
	Indicates display hold function(an external control function) is effective.	
	Indicates maximum value or minimum value hold function(an external control function) is effective.	

6 - 2 - 2. KEY OPERATION ICONS ON THE SETTING WINDOW

Key operation icons which are displayed on setting windows are shown below.

icon	Meanings	icon	meanings
Μ	MENU key		ARROW key (LEFT)
F	FUNC key		ARROW key (RIGHT)
Ε	ENTER key	*	ARROW key (UP&DOWN)
D	DISP key	\$	ARROW key (LEFT&RIGHT)
	ARROW key (UP)	¢	ARROW key (ALL)
	ARROW key (DOWN)	• P1	Pattern No. under setting


7. MODES OF OPERATION

7-1. WHAT YOU CAN DO USING THIS PRODUCT

Mode	Summary	Related Page
	Measured Value Display	
Measurement	•Can display the measured value with a numerical	
mode	number, a bar graph or a trend graph.	page20
	1. Input Setting PULSE INPUT A / PULSE INPUT B • Settings for inputs such as input type, scaling etc. for each channel. 2-INPUT CALCULATION • Settings of calculation such as formula etc. for 2 channel inputs. EXTERNAL CONTROL • Settings of external control functions which are assigned to external control terminals.	page23
Setting mode	 2. Output Setting <u>COMPARATIVE OUTPUT AL1 to AL4</u> Settings of comparative output such as compare judgement value, output mode etc. <u>PULSE OUTPUT A / PULSE OUTPUT B</u> Settings of pulse output A and pulse output B. <u>ANALOG OUTPUT</u> Setting of analog output such as output range, scaling. <u>BCD OUTPUT</u> Setting of BCD outputs such as output logic <u>RS-485 MODBUS RTU</u> Setting of communication such as unit ID, baud rate. <u>RS-232C</u> Setting of communication such as baud rate, delimiter. 	page 24

Mode	Summary	Related Page
	3. Display Setting <u>DISPLAY SELECT</u> • Selection of display in measurement mode such as numerical value, trend display etc. <u>LEVEL DISPLAY</u> • Setting of scale on level display <u>TREND DISPLAY</u> • Setting of scale on trend display	page 24
Setting Mode	 4. System Setting <u>GENERAL</u> Basic setting such as brightness of display, direction of display etc. <u>INITIALIZE</u> Setting about initialize such as initialize to user settable values or factory defaults etc. 	page 25
	5. Input-Output Diagnosis INPUT DIAGNOSIS •Makes a diagnosis to inputs. SIMULATED OUTPUT (OUTPUT TEST) •Outputs simulated signals for each output.	page25
Shortcut enabled mode	Can control external control functions which are assigned to arrow keys by operations of the keys	page139
Error mode	Displays error codes when some error occurs.	page 152

7-2. STATE TRANSITION DIAGRAM




8. MEASUREMENT MODE

8-1. WHAT YOU CAN DO IN MEASUREMENT MODE

WHAT YOU CAN DO	DESCRIPTION	RELATED PAGE
Display of measured value	Displays results of measurement	page 21
Switch of measurement displays	Switches measurement displays which are entries in advance.	page20
Shortcut functions	Executes external control functions which are assigned to arrow keys.	page139

8-2. OPERATIONS IN MEASUREMENT MODE

In the measurement mode, the following key operations are available.



Key operation	Action
DISP	Can switch measurement displays which are set in "Display select".
MENU	Moves to the setting display.
FUNC	Moves to the shortcut entry display.
$\mathbf{\overline{\otimes}}$	By holding down each key for 1 seconds (i.e. long-pressing), executes or cancels
\blacksquare	external control functions which are registered.
>	
	Executes or cancels key lock function.


When the key lock is enabled, key operations are not acceptable. Operate the keys after canceling key lock function.

8-3. MEASUREMENT VALUE DISPLAY

Along with the numerical number format, this product can display the measured value in level format (bar graph) or trend format (polygonal line graph).

8 - 3 - 1. MEASUREMENT (NUMERICAL NUMBER) DISPLAY

The measurement (numerical number) display shows measurement result in numerical number and can display 1 item to 3 items on one window.



alphabets and symbols.


Note: Other than 1.8, refer to "6-1.NAME OF EACH PART".

8 - 3 - 2. LEVEL DISPLAY (BAR GRAPH)

The level display (Bar graph) shows measurement result in level (bar graph) and numerical number. Upper limit value (right edge) and lower limit value (left edge) of level display can be set arbitrary and are

displayed on display.

The display can show 1 item or 2 items on one window.



3	Shows lower limit value (left edge) of level display (bar graph) scale for 1st item.
4	Shows upper limit value (right edge) of level display (bar graph) scale for 1st item.
5	Shows measurement result of 1st item by numerical number.
6	When any units are selected in display setting, the unit is display *The unit can be replaced by custom unit with up to 6 characters of the combination of alphabets and symbols.
Ī	Shows measurement result of 2nd item by level display (bar graph). * 2 denotes 2nd item.
8	Shows lower limit value (left edge) of level display (bar graph) for 2nd item.
9	Shows upper limit value (right edge) of level display (bar graph) for 2nd item.
10	Shows measurement result of 1st item by numerical number.
1	When any units are selected in display setting, the unit is displayed. *A custom unit, which is up to 6 characters of the combination of alphabets and symbols, can be also used as a unit.


Note: Other than ①-⑪, refer to "6-1.NAME OF EACH PART".

8 - 3 - 3. TREND DISPLAY (LINE GRAPH)

Trend display shows measurement result in a line graph, therefore the chronological change of the measurement value can be recognized simply and also shows current measurement value in numerical number.

Upper limit value (upper edge) and lower limit value (lower edge) of trend display can be set arbitrary and are displayed on display.

The display can show 1 item or 2 items on one window.



Item	Description
_	Shows the title of display which is currently displayed in measurement display.
1	* In the case of "InsA InsB", instantaneous value A is treated as 1st item and instantaneous
	value B is treated as 2nd item.
2	Shows measurement result of the 1st item by trend display (line graph).
Ŀ	* 1 denotes 1st item.
3	Shows lower limit value (lower edge) of level display (bar graph) scale for 1st item.
4	Shows upper limit value (upper edge) of level display (bar graph) scale for 1st item.
5	Shows unit of time axis (time base).
9	*The time axis (time base) is common to the 1st item and the 2nd item.
6	Shows measurement result of the 1st item in numerical number.
	When any units are selected in display setting, the unit is displayed.
\bigcirc	*A custom unit, which is up to 6 characters of the combination of alphabets and symbols,
	can be also used as a unit.
(8)	Shows measurement result of the 2nd item by trend display (line graph).
	* 2 denotes 2nd item.
(9)	Shows lower limit value (lower edge) of trend display (line graph) scale for 2nd
	item.
(10)	Shows upper limit value (upper edge) of trend display (line graph) scale for 2nd
00	item.
(11)	Shows measurement result of the 2nd item in numerical number.
	When any units are selected in display setting, the unit is displayed.
12	*A custom unit, which is up to 6 characters of the combination of alphabets and symbols,
	can be also used as a unit.

Note: Other than ①-⑫, refer to "6-1.NAME OF EACH PART".

9. SETTING MODE

9-1. WHAT YOU CAN DO IN "THE SETTING MODE"

9 - 1 - 1. WHAT YOU CAN DO IN "THE INPUT SETTING GROUP"

- ← PULSE INPUT (chA / chB) \rightarrow page36
- Select a pattern number to configure settings.
- ➤ Selects the type of the input.
- \succ Selects the analog filter of input.
- Selects voltage of supply power for sensor.
- Sets scaling for instantaneous value display.
- Selects position of decimal point for instantaneous value display.
- Selects a unit for instantaneous value display.
- Makes settings for stabilizing instantaneous value display.

*Available for models with pulse input.

LINE DRIVER INPUT (chA / chB) \rightarrow page 50

- Select a pattern number to configure settings.
- > Selects the type of the input.
- > Selects the analog filter of input.
- Selects voltage of supply power for sensor.
- Sets scaling for instantaneous value display.
- Selects position of decimal point for instantaneous value display.
- Selects a unit for instantaneous value display.
- Makes settings for stabilizing instantaneous value display.

*Available for models with line driver input.

- 2 INPUT CALCULATION SETTING \rightarrow page 61
- Select a pattern number to configure settings.
- Sets calculating formula for instantaneous value display.
- Sets decimal point for instantaneous value display.
- \succ Sets unit for instantaneous value display.
- \succ Sets step for instantaneous value display.

*Available for 2-input (A channel and B channel) models

EXTERNAL CONTROL \rightarrow page 68

- Selects a function assigned to the external control terminal 1.
- Selects a function assigned to the external control terminal 2.
- Selects a function assigned to the external control terminal 3.
- Selects a function assigned to the external control terminal 4.
- Selects a function assigned to the external control terminal 5.

9 - 1 - 2. WHAT YOU CAN DO IN "THE OUTPUT SETTING GROUP"

COMPARATIVE OUTPUTS (AL1-AL4)

SETTING →page70 —

- Select a pattern number to configure settings.
- Select source display item for comparative output.
- Select compare mode of comparative output.
- > Set ON condition of comparative output.
- ➢ Set judgement value of comparison.
- > Set delay time of comparative output.
- \succ Set output mode of comparative output.
- \succ Set logic of comparative output.
- Select color of display background when comparative output is ON.

ANALOG OUTPUT SETTING \rightarrow page 82

- Select a pattern number to configure settings.
- > Select output range of analog output.
- > Select display item to be output from
- analog output. ≻ Set scaling of analog output.

*Available for models with analog output.

RS-485 MODBUS COMMUNICATION

SETTING \rightarrow page 98

- ≻ Set unit ID.
- Set parameters for communication.

*Available for models with RS-485 Modbus.

- . BCD OUTPUT SETTING \rightarrow page 87
- Select a pattern number to configure settings.
- Select display item to be output from BCD output.
- ➢ Select output logic of BCD data.
- Select output logic of data synchronized signal.

*Available for models with BCD output.

RS-232C COMMUNICATION

SETTING \rightarrow page 92

➢ Set parameters for communication.

*Available for models with RS-232C.

9 - 1 - 3. WHAT YOU CAN DO IN "THE DISPLAY SETTING GROUP"

- DISPLAY SELECT SETTING \rightarrow page102
- > Select display items to switch.
- Select the display item to show level display.
- Select the display item to show trend display.

LEVEL DISPLAY SETTING \rightarrow page107

- Select a pattern number to configure settings.
- \succ Set display scales of the level display.

TREND DISPLAY SETTING \rightarrow page110

- Select a pattern number to configure settings.
- ➤ Set display scales of the trend display.
- \succ Set the time axis.

9 - 1 - 4. WHAT YOU CAN DO IN "THE SYSTEM SETTING GROUP"

- GENERAL SETTINGS \rightarrow page114
- ➤ Change brightness of display.
- \succ Provide wait time after power on.
- Darken the display after a specified period of time.
- Select languages of display.
- Set the direction of the display.
- > Disable changing the settings.
- ➢ Copy pattern data.

INITIALIZINGS \rightarrow page 123

- \succ Save current settings as user defaults.
- \succ Initialize to save settings.
- > Initialize to factory defaults.

9 - 1 - 5. WHAT YOU CAN DO IN "THE DIAGNOSIS GROUP"

INPUT DIAGNOSIS \rightarrow page 125

- > Check input signals are applied.
- Check status of external control
- terminals.


SIMULATED OUTPUT (OUTPUT TEST)

→page128 .

- Output simulated output to comparative output.
- Output simulated output of specified value to analog output.
- Output simulated output to each bit of BCD output.
- Display receive data and transmit data of communication.

9-2. OPERATION IN SETTING MODE 9-2-1. TRANSFER BETWEEN SETTING GROUPS

The chart below shows basic operation procedures such as transfers between each setting groups.



During the setting mode, external control inputs become disabled and the analog output and comparative judgement results hold values just before the transfer to the setting mode.

9 - 2 - 2. OPRERATING PROCEDURE

An operating procedure for a concrete setting is shown below. The chart below is an explanation for changing of the sensor power voltage.



No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories). By moving the cursor with " ARROW (UP/DOWN) " key, the selection of major categories to set can be changed.
	* On the 1st layer, by pushing the " MENU " key, the display returns to the measurement display.
2	Pointing the cursor to a major category to set and pushing " ARROW (RIGHT)" key, the display moves to the 2nd layer (small categories). By moving the cursor with " ARROW (UP/DOWN)" key, the selection of small categories of the setting can be changed. If the " ARROW (LEFT)" key is pushed, the display returns to the 1st layer.
	* On the 2nd layer, by pushing the " MENU " key, the display returns to the measurement display.
3	Pointing the cursor to a small category to set and pushing " ARROW (RIGHT) " key, the display moves to the 3rd layer (setting variables). If the " ARROW (LEFT) " key is pushed, the display returns to the 2nd layer.
	* On the 3rd layer, by pushing the " MENU " key, the display returns to the measurement display.
4	By moving the cursor with " ARROW (UP/DOWN) " key, select a setting variable. If the " ARROW (LEFT) " key is pushed, the display returns to the 2nd layer.
5	At the selected setting variable, by pushing " ARROW (RIGHT) " key, the display moves to the 4th layer (setting contents) and a current selected content has a check mark. If the " ARROW (LEFT) " key is pushed, the display returns to the 3rd layer.
6	By moving the cursor with " ARROW key (UP/DOWN) ", select content. If the " ARROW (LEFT) " key is pushed, the display returns to the 3rd layer.
7	By pushing the "ENTER" key, the selected content is confirmed and a check mark accompanies. If the " ARROW (LEFT) "key is pushed, the display returns to the 3rd layer.
8	By pushing the "MENU" key, the selected contents are stored and the display returns the measurement display.

Note: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

9-3. OVERVIEW OF PARAMETERS AND INITIAL VALUES 9-3-1. INPUT SETTING GROUP OVERVIEW

(se	(se	3rd Layer (Setting variables)		4th L	ayer (Setting values)			
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks		
		Pattern select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern 1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.		
		Input type	InputType	OpenCollector	OpenCollector/Logic/ ZeroCross/2Wire	Select input signal type		
	որսէ B ւրսէB]	Input filter	InputFilter	None	None/30Hz/1.5kHz/15kHz	Select analog input filters		
	Pulse ir PulseIn	Sensor power	SensorPower	12V	12V/24V	Switch Sensor power voltage		
	Pulse input A, Pulse input B [PulseInput A, PulseInput B]	Instantaneous value display coefficient	InsDispCoef	1.00000×10°	0.00000 to 9.99999×10 ^{.9~9}	For scaling setting of instantaneous value display,		
ft		Instantaneous Unit Time	InsUnitTime	Sec	Sec/Min/Hour	multiply frequency by instantaneous coefficient and unit time.		
1.Input		l.lnp	Instantaneous value decimal point position	InsDecPoint	####### (No decimal point)	######################################	Set number of digits after decimal point	
		Instantaneous value display unit	InsDispUnit	None	None/select from 62 units	Refer to detailed instruction manual about custom unit		
	[WPMZ-5.*P*] (Generic pulse input)	Instantaneous value auto zero	InsAutoZero	0.00	0.00 to 99.99sec	Displays 0 if no pulse input over more than setting time.		
		[WPMZ-5-*P*] (Generic pulse input)	5-*P*] se input)	Instantaneous value moving average	InsMoveAve	None	None/2times/3times /4times /5times /6times /7times /8times / 9times	Set number of moving average.
			Instantaneous value simple average	InsSimpleAve	None	None/2 times /4 times /8 times /16 times /32 times /64 times /128 times /256 times	Set number of simple average for internal sampling (10ms)	
		Instantaneous value display step	InsDispStep	None	None/5steps/10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)		

ŝ	(s	3rd Layer (Set	ting variables)	4th L	ayer (Setting values)				
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks			
		Pattern select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.			
		Input type	InputType	Line driver	Line driver	Line driver only			
	input B InputB]	Input filter	InputFilter	None	None	No analog input filter			
	ulse ulse	Sensor power	SensorPower	5V	5V	5V only			
	Pulse input A, Pulse input B [PulseInputA, PulseInputB]	Instantaneous value display coefficient	InsDispCoef	1.00000×10°	0.00000 to 9.999999×10 ^{-9~9}	For scaling setting of instantaneous value display,			
		Instantaneous Unit Time	InsUnitTime	Sec	Sec/Min/Hour	multiply frequency by instantaneous coefficient and unit time.			
1.Input		Instantaneous value decimal point position	InsDecPoint	######## (No decimal point)	######################################	Set number of digits after decimal point			
		Instantaneous value display unit	InsDispUnit	None	None/select from 62 units	Refer to detailed instruction manual about custom unit			
		Instantaneous value auto zero	InsAutoZero	0.00	0.00 to 99.99sec	Displays 0 if no pulse input over more than setting time.			
	-*L*] input)	-*L*] · input)	-*L*] : input)	5-*L*] r input)	Instantaneous value moving average	InsMoveAve	None	None/2times/3times /4times /5times /6times /7times /8times / 9times	Set number of moving average.
	[WPMZ-5-*L*] (Line driver input)	Instantaneous value simple average	InsSimpleAve	None	None/2 times /4 times /8 times /16 times /32 times /64 times /128 times /256 times	Set number of simple average for internal sampling (10ms)			
		Instantaneous value display step	InsDispStep	None	None/5steps/10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)			

(86		3rd Layer (Set	ting variables)	4th La	ayer (Setting values)						
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of Variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks					
		Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern 1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.					
	2 input calculation	Expression for instantaneous value	InsExpression	None	None/ (B/A)*100 / (B/A-1)*100 /B-A / (B/(A+B))*100 / A+B	Select expression for calculation of instantaneous value.					
		2 input calcu	2 input calcul	nput calcu	nput calcu	nput calcu	Instantaneous value decimal point position	InsDecPoint	####### (No decimal point)	########/#############################	Set number of digits after decimal point
1.Input				Instantaneous value display unit	InsDispUnit	None	None/select from 62 units	Refer to detailed instruction manual about custom unit			
1				Instantaneous value display step	InsDispStep	None	None/5steps/10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)			
	External Control	Function of external control terminal 1 to 5	ExtCtrl1Func ExtCtrl2Func ExtCtrl3Func ExtCtrl4Func ExtCtrl5Func	None	None/ CompareReset/ MeasureBlockA/ MeasureBlockB/ DispHoldA/ DispHoldB/ DispHoldA&B/ MaxHoldA/ MaxHoldB/ MaxHoldA&B/ MinHoldA/ MinHoldB/ MinHoldA&B/ PatternChange1/ PatternChange2/ PatternChange3/ MonitorChange/ TrendHold	Select functions assigned to external control terminals.					

9 - 3 - 2. OUTPUT SETTING GROUP OVERVIEW

_	_	3rd Layer (Setting variables)		4th L	4th Layer (Setting values)		
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of Variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks	
		Pattern select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.	
		Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select source output display value to compare.	
	.2 AL4	Compare mode	CompareMode	LevelJudge	LevelJudge/ ZoneJudge	Select compare mode	
	out AI tput 4	Condition of ON	OnConditions	Excess InTheZone	Excess/LessThan InTheZone/OutsideTheZone	In level judge mode In zone judge mode	
	e Outr Ive Ot			10000 0	Threshold:±999999 Hysteresis:0 to 999999	In level judge mode	
	nparative Jomparati	Comparison judgement value	Threshold	0 10000 0	Zone lower limit:±999999 Zone upper limit :±999999 Hysteresis:0 to 999999	In zone judge mode	
	Comparative Output AL1, Comparative Output AL2 Comparative Output AL3, Comparative Output AL	Comparison ON delay	OnDelay	None	None/20ms/50ms/100ms/200	Comparative output turns ON, if ON condition continues over set delay time.	
t	ative Outp arative Ou	Comparison OFF delay	OffDelay	None	ms/500ms 1s/5s/10s/20s	Comparative output turns OFF, if OFF condition continues over set delay time.	
2.Output	Compar: Compa	Output mode	OutputMode	Normal	Normal/Latch/OneShot5ms/ OneShot 10ms/ OneShot 20ms/ OneShot 50ms/ OneShot 0.1s/ OneShot 0.2s/ OneShot 0.5s/ OneShot 1s/ OneShot 2s	Select output mode of comparison	
		Output logic	OutputLogic	Negative(NO)	Positive(NC)/Negative(NO)	NC/NO are for relay output product.	
		Background Color at ON	OnBgColors	Black	Black/Red/Yellow/Green	Background color priority AL1>AL2>AL3>AL4	
		Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.	
	at	Output range	OutputRange	0-10V	0-10V/±10V/1-5V/0-20mA/4-2 0mA	Select output range (type).	
	Analog Output	Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select a displayable item for analog output	
	An	Output scale	OutputScale	0 10000	0% display value :±999999 (±99999) 100% display value : ±999999(±99999)	Set scaling for analog output. Set expected display values at 0% and 100% output.	

		3rd Layer (Set	3rd Layer (Setting variables) 4th Layer (Setting values)			
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of Variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks
		Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern 1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.
	BCD Output	Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select a displayable item for BCD output
	BCD (Data signal logic	DataSignalLogic	Negative	Positive /Negative	Select logic of data signal output.
		Synchronous signal logic	SyncSignalLogic	Negative	Positive /Negative	Select logic of synchronous signal (PC) output.
	cation	Slave Address	SlaveAddress	1	1/2/3/4/ /30/31	Set ID number.
2.Output	RS-485 communication	Baud rate	Baudrate	19200bps	9600bps/19200bps/38400bps	Set baud rate.
	Modbus	Parity	Parity	Even	None/Even/Odd	Set parity bit.
		Protocol	Protocol	Modbus-RTU	Modbus-RTU/OriginalComm and/OriginalOutput	Set protocol
	tion	Baud rate	Baudrate	19200bps	9600bps/19200bps/38400bps	Set baud rate.
	RS-232C communication	Data length	DataLength	7bit	7bit/8bit	Set data character length
	RS	Parity	Parity	Even	None/Even/Odd	Set parity bit.
		Stop bit	Stopbit	1bit	1bit/2bit	Set stop bit length.
		Delimiter	Delimiter	CR LF	CR/CR LF	Set delimiter type.

9 - 3 - 3. DISPLAY SETTING GROUP OVERVIEW

		3rd Layer (Sett	ing variables)	4th La	yer (Setting values)	
1st Layer (Large Categories)	2nd Layer (Small Categories)	Names of Variables	Character Strings on Display (Abbreviated Form)	Initial Values	Selectable Values	Remarks
	Display Select	Measure select	MeasureSelect	linput: InsA 2inputs: InsA+InsB	InsA/InsB/InsCalc/ InsA+InsB / InsCalc+A+B/ InsA+Comp/InsB+Comp/Ins Calc+Comp	Select displayable items can be switched by DISP key or external control (multiple selects are available)
	Displ	Level select	LevelSelect		InsA+InsB InsA/InsB/InsCalc/ InsA+InsB	Select an item displayed on level display
		Trend select	TrendSelect			Select an item displayed on trend display.
	A	Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.
lay	ispla	Instantaneous value A scale	InsA Scale	0 10000	Lower limit:±9999999 00 Upper limit:±9999999	Set display scale of level display.
3.Display	Level Display	Instantaneous value B scale	InsB Scale			Left edge of display is lower limit and right edge of display is higher limit
	Г	Instantaneous calculation scale	InsCalcScale			
		Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern 1/ Pattern 2/ Pattern 3/ Pattern 4/ Pattern 5/ Pattern 6/ Pattern 7/ Pattern 8	Select pattern No. to set.
	play	Instantaneous value A scale	InsA Scale		Lower limit + 000000	Set display scale of trend display.
	Trend Display	Instantaneous value B scale	InsB Scale	0 10000	Lower limit :±999999 (±99999) Upper limit :±999999	Bottom edge of display is lower limit and top edge of
	Tr_{r}	Instantaneous calculation scale	InsCalcScale		(±99999)	display is higher limit.
		Time axis	TimeAxis	1s/div	1s/div,2s/div,5s/div,10s/div,30 s/div,60s/div,120s/div	Select time for 1 division of time axis.

Se	(s	3rd Layer (Setting variables)		4th La	4th Layer(Setting values)		
1st Layer (Large Categories	2nd Layer (Small Categories)	Names of Variables	Character Strings on Display (Abbreviated For)	Initial Values	Settable Variables	Remarks	
		Brightness	Brightness	5 Bright	5 Bright/4/3/2/1 Dark/0 Off	Select brightness of display *"0 Off" is set, whole display is black out	
		Power on delay	PowerOnDelay	None	None/2sec/5sec/10sec/20sec /30sec/60sec	Select time from power on to starting measurement	
	al	Power saving time	PowerSavingTime	None	None/1min/2 min/5 min/10 min/30 min/60 min	In power saving state, brightness becomes "1 Dark" level.	
	General	Language	Language	日本語	日本語 /English	Select language	
Ę	C	Direction of display	DisplayDirection	Horizontal	Horizontal/Vertical	Select direction of display	
4.System		Setting protect	SettingProtect	Disable	Disable/Enable	If Enable, changing settings are disabled.	
		Pattern Copy	PatternCopy	Pattern1 (Copy From) PatternAll (Copy To) Execute (OperationSelect)	Pattern1/2/3/4/5/6/7/8 Pattern1/2/3/4/5/6/7/8/Patter nAll	Function of copying settings for each pattern.	
		Save user defaults	UserDefaultSave	Message "Save cu values?"	urrent settings as user initial		
	Initialize	Initialize to user defaults	UserDefaultLoad	Message "Initializ values?"	e setting values to user initial		
	-	Initialize to factory default	FactoryDefaultLoad	Message "Initiali: default?"	ze setting values to factory		

9 - 3 - 4. SYSTEM SETTING GROUP OVERVIEW

(9	(1	3rd Layer (Setting	/ariables)	4	th Layer (Test Outputs)		
1st Layer (Larze Catezories)	2nd Layer (Small Categories)	Names of variables	Character Strings on Display (Abbreviated Form)	Initial Values	Outputs (Test Result)	Remarks	
	Input Diagnosis	Pulse Input A Pulse Input B	PulseInputA PulseInputB	_	_	 Check for input signal existence. Common to "Pulse Input" and "Line driver input". 	
	Input	External control inputs	ExternalCtrl	_	_	Checks each terminal.for ON/OFF state and displays the status.	
osis		Comparative output AL1 to AL4	CompareAL1 CompareAL2 CompareAL3 CompareAL4	_	_	Outputs ON level or OFF level	
5. Diagnosis				Analog output	AnalogOutput	-	_
	Output Test	BCD Output(Data)	BCD Output(Data) BCD Output(Data)	_	Outputs ON level		
	Ou	BCD Output(PC)	BCD Output(PC)	_	_	or OFF level for each bit	
		Modbus Communication RS-485	ModbusCom	_	-	Displays receive data and transmit data	
		RS-232C	RS-232C Com	-	_	Displays receive data and transmit data	

9 - 3 - 5. DISGNOSIS OVERVIEW

9-4. DETAILS OF INPUT SETTING GROUP

The input setting group is classified into the following 4 groups which can be configured respectively.

2nd layer/ Small categories	Descriptions	Remarks
Pulse input A	- Settings for the sensor	Displayed in models with
Pulse input B	connected with. - Settings for scaling	pulse input and line driver input.
2 input calculation	Setting for the calculation of 2 channel inputs.	Displayed only in models with chB input.
External control inputs	Setting about assignments of external control terminals.	

9 - 4 - 1. PULSE INPUT A / PULSE INPUT B (WPMZ-5-*P*)

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select	page37
Select input signal type	Input type	page 38
Select input analog filter	Input filter	page 39
Select voltage of power for the sensor	Sensor power	page 40
	Instantaneous value display coefficient	
Set scaling functions for instantaneous value	Instantaneous unit time	page 41
	Instantaneous value decimal point position	
Set units for instantaneous value display	Instantaneous value display unit	page 44
Set time after that passes the instantaneous value display becomes zero	Instantaneous value auto zero	page 46
	Instantaneous value moving	
Set functions which stabilize the	average Instantaneous value simple	page 47
instantaneous value display.	average	
	Instantaneous value display step	

Only WPMZ-5-*PP-**-***, "Pulse input B" is displayed.

In this case, "PulseInputA" corresponds to the channel A input and "Pulse input B" corresponds to the channel B input.

9 - 4 - 1 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, 2 input calculations), output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings. Please pay attention to the target pattern number which the following "Pulse Input" configuration is performed to.

3rd layer Setting variable	4th layer Setting values	Initial value	Meanings of setting values	
	Pattern1		Performs a configuration to pattern No.1	
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2	
Pattern select [PatternSelect]	Pattern3		Performs a configuration to pattern No.3	
	Pattern4		Performs a configuration to pattern No.4	
	Pattern5		Performs a configuration to pattern No.5	
	Pattern6		Performs a configuration to pattern No.6	
	Pattern7		Performs a configuration to pattern No.7	
	Pattern8		Performs a configuration to pattern No.8	

•How to select "Pattern 8" is shown below.

(Same operation could be applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "1. Input" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "PulseInputA" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "PatternSelect" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select pattern No. which need to be set.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 4 - 1 - 2. Selecting Type of Input

This setting variable selects a suitable input type for the sensor you use.

3rd layer Setting variable	4th layer Setting values	Initial value	Meanings of setting values
Input type [InputType]	Open collector	*	Connecting for a sensor with NPN open collector output etc.
	Logic		Connecting for a sensor with voltage pulse or PNP open collector output etc.
	Zero cross		AC voltage signal.
	2 wire		Connecting for a proximity sensor etc.

When the input type setting is changed, the measurement function is inhibited in 50ms after returning to the measurement mode.

•How to set the input type to "Zero cross" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW(UP/DOWN) " key, point the cursor to " PulseInputA " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InputType " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " ZeroCross " *Select input type which is suitable for the sensor in use.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 1 - 3. Selecting Analog Filter for Input

The low pass filter eliminates high-frequency noise from input signal. The filer can be set to 4 kinds of cutoff frequency so that match usage environment.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values	
Input filter [InputFilter]	None	*	No low pass filter	
	30Hz		Low pass filter of 30Hz	
	1.5kHz		Low pass filter of 1.5KHz	
	$15 \mathrm{kHz}$		Low pass filter of 15KHz	

When the input filter setting is changed, the measurement function is inhibited in 50ms after returning to the measurement mode.

●How to set the input analog filter to "1.5 kHz" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW(UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW(UP/DOWN) key", point the cursor to "PulseInputA" and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "InputFilter" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1.5kHz ". *Select a parameter in conformity with the actual condition of use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing "ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
Ī	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 4 - 1 - 4. Selecting Voltage of Supply Power for the Sensor

This setting variable selects supply power voltage which is supplied to the sensor.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Sensor power [SensorPower]	12V	*	Supplies DC12V power to the sensor (100mA max.). * For 2 channel inputs, total current for chA and chB is up to 100mA.
	24V		Supplies DC24V power to the sensor (50mA max.)*For 2 channel inputs, total current for chA and chB is up to 50mA.

- When the sensor power voltage setting is changed, the measurement function is inhibited in approx. 1 second after returning to the measurement mode.

- In the case of the combination of DC12V and DC24V, the total power is $1.2~\mathrm{W}$ max.

 \bullet How to set the sensor power to "DC24V" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "PulseInputA" and push " ARROW (RIGHT) " key, then the display moves to the 3nd layer (small categories) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " SensorPower " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 24V ". *Select suitable voltage for the sensor in use.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 1 - 5. Setting Scaling for Instantaneous Value Display

Set scaling parameters of scaling settings required for measurement.

3rd layer (Settin	3rd layer (Setting variables)				
Names of variables	Character Strings on Display (Abbreviated Form)	4th layer (Setting values)	Initial value	Meanings of setting values	
Instantaneous value display coefficient	InsDispCoef	0.00000 to 9.99999×10 ^{-9~9}	1.00000×10^{0}	Scaling setting for instantaneous value display.	
T , ,	InsUnitTime	Sec	Sec	Multiplying frequency by instantaneous coefficient and unit time.	
Instantaneous Unit Time		Min			
		Hour			
	InsDecPoint	######. #			
Instantaneous value decimal point position		#####. ###		Select decimal point position for instantaneous	
		###. ###		value display.	
		##. ####			
		#. #####			

[Scaling setting examples]

1) Example 1

Detecting pulses from a gear wheel which generates 5 pulses per 1 round by proximity switch (open collector output), displays the revolving speed in [rpm].

3rd layer (Setting variables)	4th layer (Setting values)	Descriptions for setting examples
Input type [InputType]	Open collector	The sensor is an NPN open collector type, therefore "open collector" should be selected as the input type.
Instantaneous value display coefficient [InsDispCoef]	2.00000×10 ⁻¹	 (Setting for Instantaneous revolving speed display) For setting of Instantaneous display coefficient, number of rotation per 1 pulse is needed. Calculate the number of rotation per 1 pulse. Because of 5 [Pulse] per 1 round, therefore, 1/5=2×10⁻¹[round] Set " 2.00000×10⁻¹" as the Instantaneous display coefficient
Instantaneous Unit Time [InsUnitTime]	Min	Unit to display is [rpm], therefore, select " Min " for the instantaneous unit time.
instantaneous decimal point position [InsDecPoint]	######	Displays without decimal point, therefore select "#######" for Instantaneous value decimal point position

• Setting method of instantaneous display coefficient and Instantaneous Unit Time is shown below. Setting procedures for other setting variables are same. (Same operation is also applied to the pulse input B.)

(Measurement display) 2nd layer 1st layer Setting 1. Input InsCal ΠA ≫ ≫ 2. Output ■ PulseInputB 3. Display + 2InputCalc ∃ ExternalCtrl Moves to 3rd 4. System layer by right 5. Diagnosis arrow key. M Back Back Next 🕨 Next 🕨 Moves to 2nd layer by Moves to setting display(1st layer)by right arrow key. MENU kev. 3rd layer 3rd layer 4th layer < 🏾 PulseInputA < 🛯 PulseInputA < TA < InsDispCoet InputType CoefPerPulse \gg InputType InputFilter ENTER InputFilter SensorPower Moves to SensorPower numerical value InsDispCoef InsUnitTime setting display by ENTER key. Next 🕨 Back Back Next 🕨 Back Enter E Moves to instantaneous display Moves to 4th layer by right arrow key. coefficient by down arrow key. 4th layer (numerical 4th layer (numerical value setting) value setting) 4th layer < 🛯 < InsDispCoef 🖪 < InsDispCoef < 🛯 < InsDispCoef \gg CoefPerPulse CoefPerPulse CoefPerPulse \ll \ll +2.00000 × 10-1 +1.00000 × 10+9 ENTER Returns to 3rd layer by left arrow key. 😔 Change Enter E Back 🔄 Change Enter E Enter E Selects numerical value by arrow Registers selected numerical keys (up/down/left/right) value by ENTER key. 3rd layer 3rd layer 4th layer < 🖪 PulseInputA 🖪 PulseInputA 🖪 < InsUnitTime InputType InputType InputFilter InputFilter Min ≫ ≫ SensorPowe SensorPower Hour InsDispCoef Moves to minute by InsUnitTime down arrow key. Back Next 🕨 Back Next 🕨 Back Enter E Moves to 4th layer Moves to instantaneous unit time by right arrow key. by down arrow key 4th layer 4th layer 3rd layer 🛯 🖪 🖓 InsUnitTime < 🖪 < InsUnitTime < 🖪 PulseInputA InputType Sec Sec $\|$ ENTER InputFilter SensorPower Hour Hou InsDispCoef Next 🕨 Back Back Enter E Back Enter E Returns to 3rd Registers selected setting layer by left MENU value by ENTER key. arrow key. \ll Stores selected parameters Returns to 2nd layer and returns measurement by left arrow key. display by MENU key. (Measurement display) InsCalc

2) Example 2

When maximum flow rate is approx. $40[\ell/min]$, using a sensor of rating 7.5[m ℓ /Pulse] (NPN open collector type), instantaneous flow rate will be displayed in [ℓ/min] with 3 decimal places.

3rd layer (Setting variables)	4th layer (Setting values)	Descriptions for setting examples
Input type [InputType]	Open collector	The sensor is an open collector output type, therefore select "open collector" as input type.
Instantaneous value display coefficient [InsDispCoef]	$7.50000 imes 10^{-3}$	 (Setting for instantaneous flow rate display) Set flowrate per 1 pulse as instantaneous display coefficient Although instantaneous flow rate will be displayed in [l/min], the rating of the sensor is 7.5[ml/Pulse], it should be converted to7.5×10⁻³[l/Pulse]. Set the "Instantaneous display factor" as "7.50000×10^{-39"}
Instantaneous Unit Time [InsUnitTime]	Min	Displayed unit is $[\ell/min]$, therefore select " Min " as the instantaneous unit time.
instantaneous decimal point position [InsDecPoint]	####. ####	To display 3 digits after the decimal point, select "###.###" for "instantaneous decimal point position".

*Setting procedures are same as Example 1. Refer to example 1.

3) Example 3

Using a sensor (Voltage output type) which outputs 15 [Hz] for $90[\ell/min]$, instantaneous flow rate will be displayed in $[\ell/sec]$ without a decimal point.

3rd layer (Setting variables)	4th layer (Setting values)	Descriptions for setting examples
Input type [InputType]	Logic	The sensor is voltage output type, therefore select "Logic" for "input type".
Instantaneous value display coefficient [InsDispCoef]	1.00000×10 ⁻¹	 (Setting for instantaneous flow rate display) Set flowrate per 1 pulse as "instantaneous display coefficient". Calculate number of pulses per 1 [ℓ]. The sensor outputs pulses of 15[Hz] at 90[ℓ/min], therefore, (15×60)/90=10[Pulse/ℓ]. Calculate flowrate par 1 pulse. Number of pulses per 1 litter is 10[Pulse/ℓ], therefore, 1/10=1×10⁻¹[ℓ/Pulse]. Set "1.0000×10⁻¹" for the "instantaneous value display coefficient". * Any of "1.0000×10⁻¹", "0.10000×10⁰" and "0.01000×10¹" for the "instantaneous value display coefficient" bring same results.
Instantaneous Unit Time [InsUnitTime]	Sec	Unit to display is [l/sec], therefore, select "Sec" for the "instantaneous unit time".
instantaneous decimal point position [InsDecPoint]	######	Displays without decimal point, therefore select "######" for Instantaneous value decimal point position

*Setting procedures are same as Example 1. Refer to Example 1.

9 - 4 - 1 - 6. Set Units for Instantaneous Value Display

Units for the instantaneous value display can be set.

The WPMZ has 62 selectable units. If you cannot find a suitable unit among them, you can compose custom unit up to 6 characters.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value display unit [InsDispUnit]	None, μA,mA,A,kA, μV,mV,V,kV,VA, W,kW,MW, μm,mm,cm,m, Ω,kΩ,MΩ, g,kg, N,kN,MN, Pa,kPa,MPa,hPa, J,kJ,MJ, Hz,kHz,MHz, m ³ , mm/s,mm/min, cm/min, m/s,m/min,m/h,m/s ² , m ³ /s,m ³ /min,m ³ /h, kg/h,kg/m ² ,kg/m ³ , N/m ² , ℓ,ℓ/s,ℓ/min,ℓ/h, %,%0,%RH, °C, pH,ppm,rpm,t,inch, custom unit	None	Set unit for instantaneous value display.

If you choose the custom unit, define the unit in the 5th layer. Characters which can be used in custom unit are alphabets "a" to "z", "A" to "Z" and marks.

 $(marks: [,], (,), _{1,2,3}, ^{1}, ^{2}, ^{3}, \mu, \Omega, g, \cdot, /, \ell, \%, \%_{0}, ^{\circ}, , ")$

[Display unit setting example]


1) Example 1

The method for setting the display unit of Instantaneous value to "m/s" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to " PulseInputA " and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsDispUnit " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
6	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " m/s ". *Select a proper unit for your use.
6	Pushing "ENTER" key, selected parameter becomes valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

2) Example 2

As the display unit for the instantaneous value, steps of making a custom unit of "rps" are shown below. (Same steps are also applied to the pulse input B.)




9 - 4 - 1 - 7. Setting Time for Instantaneous Value Set to Zero

As input gets closer to 0 Hz, the pulse period gets longer, and the displayed value is not updated waiting a pulse input.

If a pulse is not detected before setting time, judging no input, the displayed value becomes "0".

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value auto zero [InsAutoZero]	00.00 to 99.99s	00.00s	Set waiting time for input pulse. *The unit is "Second". By setting to 0.00, the function is disabled.

•How to set the waiting time for input pulse (Instantaneous value auto zero) to 1 second is shown below. (Same operation is also applied to the pulse input B.)



9 - 4 - 1 - 8. Stabilizing Instantaneous Value Display (Instantaneous Value Moving Average)

This setting variable set the number of moving average for input pulse.

Instantaneous value of an impeller which has a difference to the installation angles of the blades is not stable. To reduce it, the number of moving average for the number of the blades can be set.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	
	2times		
	3times		
Instantaneous	4times		
Value Moving Average	5times		Sets the number of moving average for input pulse.
[InsMoveAve]	6times		
	7times		
	8times		
	9times		

•A method to set the moving average to "5 times" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to "PulseInputA" and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsMoveAve " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 5 times ". *Select a parameter in conformity with the actual condition of use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 4 - 1 - 9. Stabilizing Instantaneous Value Display (Instantaneous Value Simple Average)

The simple average is not an average of input pulses but an average in multiple internal sampling periods (calculation periods).

Internal sampling period (calculation period) is 10ms. Each of this period, comparative outputs, analog output and BCD outputs are outputted. *If Instantaneous Value Simple Average are set to 2 to 256, PC signal of BCD outputs (synchronization signal of BCD data) is output in 10ms period.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No average. Update interval of data is 10ms.
	2times		Update interval of data is 20ms.
	4 times		Update interval of data is 40ms.
Instantaneous	8times		Update interval of data is 80ms.
value simple average	16 times		Update interval of data is 160ms.
[InsSimpleAve]	32times		Update interval of data is 320ms.
	64 times		Update interval of data is 640ms.
	128 times		Update interval of data is 1.28s.
	256times		Update interval of data is 2.56s.

•A method to set the simple average to "32 times" is shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN) key", point the cursor to "PulseInputA" and push "ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsSimpleAve " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 32times ". *Select a parameter in conformity with the actual condition of use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
(7)	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 1 - 1 0. Stabilizing Instantaneous Value Display (Instantaneous Value Display Step)

By adjusting the LCD (least significant digit) of instantaneous display value, drift of the displayed value is suppressed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	LSD 0 to 9 (No adjusting)
Instantaneous value display step	5steps		LSD 0 or 5 Adjusts 0-4 to "0" and 5-9 to "5".
[InsDispStep]	10steps		LSD 0 Adjusts 0-9 to "0" * LSD is fixed to "0".

 \bullet A method to set the display step to "10 steps" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to "PulseInputA" and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsDispStep " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 10steps ". *Select a step number in conformity with the actual condition of use.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 2. LINE DRIVER INPUT A / LINE DRIVER INPUT B (WPMZ-5-*L*)

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select	Page50
Select input signal type	Input type	page 51
Select input analog filter	Input filter	page 51
Select voltage of power for the sensor	Sensor power	page 51
	Instantaneous value display coefficient	
Set scaling functions for instantaneous value	Instantaneous unit time	page 52
	Instantaneous value decimal point position	
Set units for instantaneous value display	Instantaneous value display unit	page 54
Set time after that passes the instantaneous value display becomes zero	Instantaneous value auto zero	page 56
	Instantaneous value moving	
Set functions which stabilize the instantaneous value display.	average Instantaneous value simple average	page 57
	Instantaneous value display step	

•Only WPMZ-5-*LL-**-***, "Pulse input B" is displayed. In this case, **"PulseInputA"** corresponds to the channel A input and "Pulse input B" corresponds to the channel B input.

9 - 4 - 2 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, 2 input calculations), output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings. Please pay attention to the target pattern number which the following "Pulse Input" configuration is performed to.

3rd layer Setting variable	4th layer Setting values	Initial value	Meanings of setting values	
	Pattern1		Performs a configuration to pattern No.1	
	Pattern2		Performs a configuration to pattern No.2	
	Pattern3		Performs a configuration to pattern No.3	
Pattern select	Pattern4	Pattern number which is selected	Performs a configuration to pattern No.4	
[PatternSelect]	Pattern5	in measurement mode.	Performs a configuration to pattern No.5	
Pattern6 Pattern7	Pattern6	moue.	Performs a configuration to pattern No.6	
	Pattern7		Performs a configuration to pattern No.7	
	Pattern8		Performs a configuration to pattern No.8	

•How to select "Pattern 8" is shown below.

(Same operation could be applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "1. Input" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "PulseInputA" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "PatternSelect" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
Ī	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select pattern No. which need to be set.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
Ø	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 4 - 2 - 2. Selecting Type of Input

On a line driver input model (WPMZ-5-*L*), although input type setting menu appears, the setting variable cannot be changed.

3rd layer Setting variable	4th layer Setting values	Initial value	Meanings of setting values
Input type [InputType]	LineDriver	*	Can be connected to a device which has RS-422 compatible line driver output on one-on-one level.

9 - 4 - 2 - 3. Selecting Analog Filter for Input

On a line driver input model (WPMZ-5-*L*), although analog filter setting menu appears, the setting variable cannot be changed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Input filter [InputFilter]	None	*	No low pass filter

9 - 4 - 2 - 4. Selecting Voltage of Supply Power for the Sensor

On a line driver input model (WPMZ-5-*L*), although sensor power setting menu appears, the setting variable cannot be changed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Sensor power [SensorPower]	$5\mathrm{V}$	*	Supplies DC5V power to the sensor (200mA max.). * For 2 channel inputs, total current for chA and chB is up to 200mA.

9 - 4 - 2 - 5. Setting Scaling for Instantaneous Value Display

Set scaling parameters of scaling settings required for measurement.

3rd layer (Settin	ng variables)			
Names of variables	Character Strings on Display (Abbreviated Form)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value display coefficient	InsDispCoef	0.00000 to 9.999999×10 ^{-9 to 9}	1.00000×10º	Scaling setting for instantaneous value display.
T / /		Sec	Sec	Multiplying frequency by instantaneous coefficie and unit time.
Instantaneous Unit Time	InsUnitTime	Min		and diffe time.
		Hour		
		######		
		######. #		
Instantaneous	InsDecPoint	#####. ###		Select decimal point position for instantaneous
value decimal point position	InsDecPoint	###. ###	######	value display.
P P		##. ####		
	#. ######			


[Scaling setting examples]

1) Example 1

Attach the rotary encoder of the line driver output type which gives 40 [Pulse] per rotation to the shaft of the rotating object, and display the rotation speed of the rotating object up to the third decimal place with [rpm].

3rd layer (Setting variables)	4th layer (Setting values)	Descriptions for setting examples
Input type [InputType]	LineDriver	
Instantaneous value display coefficient [InsDispCoef]	2.50000×10^{-2}	 (Setting for displaying the rotation speed of the object) Set the number of revolutions per pulse. •Calculate the number of revolutions per pulse. Since it is 40 [Pulse] in one revolution, 1/40 = 0.025 = 2.5 × 10 · 2 [rotation]. •Set the "instantaneous value display coefficient" to "2.50000 × 10 · 2".
Instantaneous Unit Time [InsUnitTime]	Min	Displayed unit is [rpm], therefore select "minute" as the instantaneous unit time.
instantaneous decimal point position [InsDecPoint]	####. ####	To display 3 digits after the decimal point, select "###.###" for "instantaneous decimal point position".

•Setting method of instantaneous display coefficient and Instantaneous Unit Time is shown below. Setting procedures for other setting variables are same.



9 - 4 - 2 - 6. Set Units for Instantaneous Value Display

Units for the instantaneous value display can be set.

The WPMZ has 62 selectable units. If you cannot find a suitable unit among them, you can compose custom unit up to 6 characters.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value display unit [InsDispUnit]	None, μA,mA,A,kA, μV,mV,V,kV,VA, W,kW,MW, μm,mm,cm,m, Ω,kΩ,MΩ, g,kg, N,kN,MN, Pa,kPa,MPa,hPa, J,kJ,MJ, Hz,kHz,MHz, m ³ , mm/s,mm/min, cm/min, m/s,m/min,m/h,m/s ² , m ³ /s,m ³ /min,m ³ /h, kg/h,kg/m ² ,kg/m ³ , N/m ² , ℓ,ℓ/s,ℓ/min,ℓ/h, %,%0,%RH, °C, pH,ppm,rpm,t,inch, custom unit	None	Set unit for instantaneous value display.

If you choose the custom unit, define the unit in the 5th layer. Characters which can be used in custom unit are alphabets "a" to "z", "A" to "Z" and marks.

 $(marks: [,], (,), _{1,2,3}, ^{1}, ^{2}, ^{3}, \mu, \Omega, g, \cdot, /, \ell, \%, \%_{0}, ^{\circ}, , ")$

[Display unit setting example]

1) Example 1


The method for setting the display unit of Instantaneous value to "rpm" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to " PulseInputA " and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsDispUnit " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " rpm ". *Select a proper unit for your use.
6	Pushing "ENTER" key, selected parameter becomes valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

Note: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

2) Example 2

As the display unit for the instantaneous value, steps of making a custom unit of "rad/s" are shown below. (Same steps are also applied to the pulse input B.)




9 - 4 - 2 - 7. Setting Time for Instantaneous Value Set to Zero

As input gets closer to 0 Hz, the pulse period gets longer, and the displayed value is not updated waiting a pulse input.

If a pulse is not detected before setting time, judging no input, the displayed value becomes "0".

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value auto zero [InsAutoZero]	00.00 to 99.99s	00.00s	Set waiting time for input pulse. *The unit is "Second". By setting to 0.00, the function is disabled.

•How to set the waiting time for input pulse (Instantaneous value auto zero) to 1 second is shown below. (Same operation is also applied to the pulse input B.)



9 - 4 - 2 - 8. Stabilizing Instantaneous Value Display (Instantaneous Value Moving Average)

This setting variable set the number of moving average for input pulse.

Instantaneous value of an impeller which has a difference to the installation angles of the blades is not stable. To reduce it, the number of moving average for the number of the blades can be set.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	
	2times		
	3times		
Instantaneous	4times		
Value Moving Average	5times		Sets the number of moving average for input pulse.
[InsMoveAve]	6times		
	7times		
	8times		
	9times		

•A method to set the moving average to "5 times" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to " PulseInputA " and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsMoveAve " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 5 times ". *Select a parameter in conformity with the actual condition of use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 4 - 2 - 9. Stabilizing Instantaneous Value Display (Instantaneous Value Simple Average)

The simple average is not an average of input pulses but an average in multiple internal sampling periods (calculation periods).

Internal sampling period (calculation period) is 10ms. Each of this period, comparative outputs, analog output and BCD outputs are outputted.

*If Instantaneous Value Simple Average are set to 2 to 256, PC signal of BCD outputs (synchronization signal of BCD data) is output in 10ms period.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No average. Update interval of data is 10ms.
	2times		Update interval of data is 20ms.
	4 times		Update interval of data is 40ms.
Instantaneous	8times		Update interval of data is 80ms.
value simple average	16 times		Update interval of data is 160ms.
[InsSimpleAve]	32times		Update interval of data is 320ms.
	64 times		Update interval of data is 640ms.
	128 times		Update interval of data is 1.28s.
	256times		Update interval of data is 2.56s.

•A method to set the simple average to "32 times" is shown below.

(Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to "PulseInputA" and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsSimpleAve " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 32times ". *Select a parameter in conformity with the actual condition of use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 2 - 1 0. Stabilizing Instantaneous Value Display (Instantaneous Value Display Step)

By adjusting the LSD (least significant digit) of instantaneous display value, drift of the displayed value is suppressed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	LSD 0 to 9 (No adjusting)
Instantaneous value display step	5steps		LSD 0 or 5 Adjusts 0-4 to "0" and 5-9 to "5".
[InsDispStep]	10steps		LSD 0 Adjusts 0-9 to "0" * LSD is fixed to "0".

 \bullet A method to set the display step to "10 steps" is shown below. (Same operation is also applied to the pulse input B.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to " PulseInputA " and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "InsDispStep" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 10steps ". *Select a step number in conformity with the actual condition of use.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 3. 2-INPUT CALCULATION

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select [PatternSelect]	page62
Select Calculation Expression for 2-Input Instantaneous values	Expression for instantaneous values [InsExpression]	page 63
Set decimal point position of calculation result for instantaneous values	Instantaneous value decimal point position [InsDecPoint]	page 64
Set variation width for instantaneous calculation result	Instantaneous value display step [InsDispStep]	page 65

These setting variables appear only on WPMZ-5-*PP-**-*** and WPMZ-5-*LL-**-***.

9 - 4 - 3 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, 2-input calculation), output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings. Design contents related to"2 InputCalc" are registered in the pattern number selected.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	Pattern1		Performs a configuration to pattern No.1
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2
	Pattern3		Performs a configuration to pattern No.3
Pattern select	Pattern4		Performs a configuration to pattern No.4
[PatternSelect]	Pattern5		Performs a configuration to pattern No.5
	Pattern6		Performs a configuration to pattern No.6
	Pattern7		Performs a configuration to pattern No.7
	Pattern8		Performs a configuration to pattern No.8

•Setting steps to set pattern number to "Pattern8" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2-InputCalc" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "PatternSelect" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Patern8" *Select the pattern number which you need to be configured.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	e: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

9 - 4 - 3 - 2. Select Calculation Expression for 2-Input Instantaneous Value

This setting variable selects a calculation equation for instantaneous values of the A channel input and the B channel input.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No calculation
	AbsRatio (B/A)×100		Expression for absolute ratio
Expression for instantaneous	ErrRatio (B/A-1)×100		Expression for error ratio
values [InsExpression]	Err B-A		Expression for error
[IIISExpression]	Dens (B/(A+B))×100		Expression for density
	SUM A+B		Expression for sum

"A" in the calculation expressions denotes "A Channel Input" and "B" in the calculation expressions denotes "B Channel Input".

 $Please \ pay \ attention \ to \ the \ relationship \ of \ A \ and \ B \ in \ the \ calculation \ expressions.$

•Setting steps which select expression for instantaneous values to "Dens (B/(A+B))×100" are sh	own
below.	

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1 . Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN) key", point the cursor to "2 InputCalc" and push "ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "InsExpression (Expression for Instantaneous Values)" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "Dens (B/(A+B))×100". *Select a proper expression for your usage.
6	Pushing "ENTER" key, selected parameter becomes valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\overline{O}	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 3 - 3. Set Decimal Point Position of Calculation Result for Instantaneous Values

This setting variable selects position of decimal point of calculation result for instantaneous values.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	+++++++++++++++++++++++++++++++++++++++	*	
Instantaneous	##### . #		
value decimal	#### . ##		Set decimal point position of calculation result for
point position	####. ####		instantaneous values.
[InsDecPoint]	###. ######		
	#. #####		

•Setting steps to display the calculation result of instantaneous values down to 2 decimal points are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN) " key, point the cursor to "1. Input " and push "ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2 InputCalc" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "InsDecPoint" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "#####.###" * Select the pattern number which you need to be configured. *Select a proper option for your usage.
6	Pushing "ENTER" key, selected parameter becomes valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 3 - 4. Set Variation Width for Instantaneous Calculation Result

This function reduces the fluctuation of the displayed value by correcting the least significant digit (LSD) of it.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	LSD 0 to 9 (No correction)
Instantaneous value display step	5 steps		LSD 0, 5 Correct 0 to 4 to "0", 5 to 9 to "5".
[InsDispStep]	10 steps		LSD 0 Correct 0 to 9 to "0" *LSD is fixed to "0"

•Setting steps to set display step to "10 steps" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2 InputCalc" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "InsDispStep" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "10 Steps" *Select a proper steps for your use.
6	By pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *By pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

9 - 4 - 3 - 5. Set Units for Calculation Result of Instantaneous Values

For a calculation result of instantaneous values, a unit can be selected.

This product has 62 selectable units. If you cannot find a suitable unit among them, you can compose custom unit up to 6 characters.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Instantaneous value display unit [InsDispUnit]	None, μ A,mA,A,kA, μ V,mV,V,kV,VA, W,kW,MW, μ m,mm,cm,m, Ω ,k Ω ,M Ω , g,kg, N,kN,MN, Pa,kPa,MPa,hPa, J,kJ,MJ, Hz,kHz,MHz, m ³ , mm/s,mm/min, cm/min, m/s,m/min,m/h,m/s ² , m ³ /s,m ³ /min,m ³ /h, kg/h,kg/m ² ,kg/m ³ , N/m ² , ℓ , ℓ /s, ℓ /min, ℓ /h, %,%0,%RH, °C, pH,ppm,rpm,t,inch, custom unit	None	Set unit for instantaneous value display.

If you choose the custom unit, define the unit in the 5th layer. Characters which can be used in custom unit are alphabets "a" to "z", "A" to "Z" and marks.

 $(marks: [,], (,), _{1,2,3}, ^{1}, ^{2}, ^{3}, \cdot, \mu, \Omega, g, \cdot, /, \ell, \%, \%_{0}, ^{\circ}, , ")$

[Display Unit Setting Example]

1) Example 1

The steps to set the display unit of instantaneous value to "Hz" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
	By moving the cursor with "ARROW (UP/DOWN) key", point the cursor to "2InputCalc" and push "ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " InsDispUnit " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Hz ". *Select a proper unit for your usage in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

2) Example 2

Setting steps to make a custom unit "min⁻¹" for a instantaneous value display unit are shown below. (The same steps could be applied to the analog input B.)



by left arrow key.

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
	Terminal 1 function	page68
	Terminal 2 function	
Select functions assigned to each external control terminal.	Terminal 3 function	
external control terminal.	Terminal 4 function	
	Terminal 5 function	

9 - 4 - 4. EXTERNAL CONTROL

9 - 4 - 4 - 1. Select Functions Assigned to Terminals 1 to 5

These setting variables select functions from 18 functions of external control for each terminal. *Functions of terminals 1 to 5 are configured individually.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	Assigns no function.
	Compare Reset		Assigns "compare reset" function.
	Measure Block A		Assigns "measurement inhibit" function for chA.
	Measure Block B		Assigns "measurement inhibit" function for chB *Displayed only chB input is available.
Terminal 1	Measure Block A&B		Assigns "measurement inhibit" function of chA and chB. *Displayed only chB input is available.
function	DispHold A		Assigns "current value hold" function for chA.
[ExtCtrl1Func]	DispHold B		Assigns "current value hold" function for chB. *Displayed only chB input is available.
Terminal 2 function [ExtCtrl2Func]	DispHold A&B		Assigns "current value hold" function for chA and chB. *Displayed only chB input is available.
Terminal 3	MaxHold A		Assigns "maximum value hold" function for chA.
function [ExtCtrl3Func]	MaxHold B		Assigns "maximum value hold" function for chB. *Displayed only chB input is available.
Terminal 4 function	MaxHold A&B		Assigns "maximum value hold" function for chA and chB. *Displayed only chB input is available.
[ExtCtrl4Func]	MinHold A		Assigns "minimum value hold" function for chA.
Terminal 5 function	MinHold B		Assigns "minimum value hold" function for chB. *Displayed only chB input is available.
[ExtCtrl5Func]	MinHold A&B		Assigns "minimum value hold" function for chA and chB. *Displayed only chB input is available.
	Pattern Change 1		Assigns "pattern select (1st bit)" function.
	Pattern Change 2		Assigns "pattern select (2nd bit)" function.
	Pattern Change 3		Assigns "pattern select (3rd bit)" function.
	Monitor Change		Assigns "monitor change" function.
	Trend Hold		Assigns "trend hold" function.


•The setting steps to assign "MeasureBlockA" to terminal 2 are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " 1. Input " and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) key", point the cursor to "ExternalCtrl" and push " ARROW (RIGHT) key", then the display moves to the 3rd layer (setting variables) .
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " ExtCtrl2 Func " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " MeasureBlockA ". *Select a proper option for your usage.
6	Pushing "ENTER" key, selected parameter becomes valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display content returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected parameters are stored and display returns the measurement display.

Note: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

If functions which assigned to terminal 1 to 5 overlap (except "NONE"), the following message is deployed.

In this case, push "ENTER" key to return to setting display and configure again to prevent the overlap.



9-5. DETAIL OF OUTPUTSETTING GROUP

The output setting group is classified to the following small 5 categories and can be configured respectively.

2nd layer (Small categories)	Descriptions	Remarks
Comparative output AL1		
Comparative output AL2	Settings related to comparative	
Comparative output AL3	outputs.	
Comparative output AL4		
Analog output	Settings related to the analog output.	Displayed only with an analog output option.
BCD output	Settings related to the BCD output.	Displayed only with a BCD output option.
RS-232C communication	Settings related to the RS-232C communication.	Displayed only with a RS-232C communication option.
Modbus communication	Settings related to the Modbus communication.	Displayed only with Modbus communication option.

9 - 5 - 1. COMPARATIVE OUTPUT AL1 - 4

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select [PatternSelect]	page71
Select displayable source item for comparative output	Output Display Value [OutputDispValue]	page 72
Select compare mode of comparative output	Compare mode [CompareMode]	page 73
Set condition that comparative outputs turn on	Condition of ON [OnConditions]	page 74
Set comparison judgement value	Comparison judgement value [Threshold]	page 75
Cat dalay time of commonsting output	Comparison ON delay [OnDelay]	page 77
Set delay time of comparative output	Comparison OFF delay [OffDelay]	page 78
Set output mode of comparative output	Output Mode [OutputMode]	page 79
Set output logic of comparative output	Output Logic [OutputLogic]	page 80
Set background color at comparative output ON state	Background Color at ON [OnBgColors]	page 81

9 - 5 - 1 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, analog input A/B, 2 input calculations), output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings.

Design contents related to "Comparative Output" are registered in the pattern number selected.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meaning of setting value		
	Pattern1		Performs a configuration to pattern No.1		
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2		
	Pattern3		Performs a configuration to pattern No.3		
Pattern select	Pattern4				Performs a configuration to pattern No.4
[PatternSelect]	Pattern5		Performs a configuration to pattern No.5		
	Pattern6		Performs a configuration to pattern No.6		
	Pattern7			Performs a configuration to pattern No.7	
	Pattern8		Performs a configuration to pattern No.8		

•Setting steps to set the "Pattern select" to "Pattern8" are shown below. (Same steps could be applied to AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "CompareAL1" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PatternSelect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select the pattern number which you need to be configured.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not stor

9 - 5 - 1 - 2. Select Displayable Source Item for Comparative Output

Comparative outputs AL1-AL4 can be configured independently and are needed to be selected which displayable source items (source output display values) are applied to.

For example, the instantaneous measured value of chA is assigned to AL1, the instantaneous measured value of chB is assigned to AL2, the instantaneous calculated value is assigned to AL3 and AL4, etc. To each displayable source item, comparative outputs can be assigned arbitrarily.

Because multiple items are selectable for comparative outputs, item to use for compare should be selected by this setting variable.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No comparative output
Source output	InsA		Compare to instantaneous measured value of chA.
display value [OutputDispValue]	InsB		Compare to instantaneous measured value of chB. *Displayed in the option with chB input only.
	InsCalc		Compare to instantaneous calculated value of chA & chB *Displayed in the option with chB input only.

•Setting steps to set displayable source item of comparative output AL1 to "InsA" (instantaneous value of chA). Same stone could be applied to comparative outputs AI 2 - AI A

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareAL1 " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputDispValue " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "InsA". *Select a desired source item in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 3. Select Compare Mode of Comparative Output

Modes of comparison in comparative output function have 2 modes of "Level judge mode" and "Zone judge mode".

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Compare mode [CompareMode]	Level judge [LevelJudge]	*	Compare to 1 judgement value in magnitude (high/low) relation.
	Zone judge [ZoneJudge]		Compare to 2 judgement values in inclusion (in/out) relation.

•Setting steps to compare mode of comparative output AL1 to "Zone judge" are shown below. (Same steps could be applied to comparative out AL2 - AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareAL1 " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareMode " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "ZoneJudge". *Select a compare mode for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 4. Set Condition That Comparative Outputs Turn On

.

This setting variable selects the condition that makes comparative output turn ON in comparison with comparison judgement values.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
	Compare mode in "	Level	*Displayed only when compare mode is
	judgement"		level judgement
	Excess	*	Comparative output is ON when displayed
			value excess judgement value.
Condition of	LessThan		Comparative output is ON when displayed
ON			value is less than judgement value.
011	Compare mode in "Zone		*Displayed only when compare mode is
(OnConditions)	judgement"		zone judgement
	InTheZone	*	Comparative output is ON when displayed
			value is between 2 judgement values.
	OutsideTheZone		Comparative output is ON when displayed
	OutsideTheZone		value is outside of 2 judgement values.

•The setting steps to set "OnConditions" of comparative output AL1 to "LessThan" are shown below.

(The same steps could be applied to comparative output AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "CompareAL1" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "OnCondetions" and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting values). *In the 4th layer, the currently selected parameter accompanies a check mark.
8	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Less Than ". *Select a desired condition for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 5. Set Comparison Judgement Value


This setting variable determines comparison judgement values (thresholds) and hysteresis widths.

3rd layer (Setting variable)	4th layer (Setting values)	Initial values	Meanings of setting values
	Compare mode in "Level judgement"		*Displayed only when compare mode is level judgement
	Threshold	10000	
Comparison	hysteresis	0	
Judgement Value	Compare mode in "Zone judgement"		*Displayed only when compare mode is zone judgement
[Threshold]	Zone lower limit	0	
	Zone upper limit	10000	
	hysteresis	0	

• <u>Setting method of compare judgement value in level judgement of compare mode</u>

The setting steps to set threshold of comparative output AL1 to "50000" are shown below. For the hysteresis, the same steps could be applied.

(The same steps could be applied to comparative output AL2 -AL4.)




•<u>Setting method of compare judgement value (zone judgement value) in zone judgement of compare</u> <u>mode</u>

The setting steps to set zone upper limit to "50000" are shown below.

The same steps could be applied to zone lower limit and hysteresis.

(The same steps could be applied to comparative output AL2 - AL4.)



9 - 5 - 1 - 6. Set Delay Time of Comparative Output (Comparison ON Delay)

Comparison ON delay is the delay function which the output does NOT turn on immediately after meeting the compare ON condition, but after keeping on setting time continuously turns ON.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No output ON delay
	20ms		Output ON delay 20ms
	$50 \mathrm{ms}$		Output ON delay 50ms
	100ms		Output ON delay 100ms
Comparison ON	200ms		Output ON delay 200ms
Delay	$500 \mathrm{ms}$		Output ON delay 500ms
[OnDelay]	1s		Output ON delay 1s
	5s		Output ON delay 5s
	10s		Output ON delay 10s
-	20s		Output ON delay 20s

•Setting steps to set output ON delay of comparative output AL1 to "200ms" are shown below. (Same steps could be applied to Comparative output AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareAL1 " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OnDelay " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "200ms". *Select a desired delay time for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
(7)	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 7. Set Delay Time of Comparative Output (Comparison OFF Delay)

Comparison OFF delay is the delay function which the output does NOT turn off immediately after meeting the compare OFF condition, but after keeping on setting time continuously turns OFF.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No output OFF delay
	20ms		Output OFF delay 20ms
	50ms		Output OFF delay 50ms
	100ms		Output OFF delay 100ms
Comparison OFF	200ms		Output OFF delay 200ms
Delay [OffDelay]	$500 \mathrm{ms}$		Output OFF delay 500ms
[OIIDelay]	$1\mathrm{s}$		Output OFF delay 1s
	5s		Output OFF delay 5s
	10s		Output OFF delay 10s
	20s		Output OFF delay 20s

•Setting steps to set output OFF delay of comparative output AL1 to "200ms" are shown below. (Same steps could be applied to Comparative output AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareAL1 " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OffDelay " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "200ms". *Select a desired delay time for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 8. Set Output Mode of Comparative Output

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	Normal	*	While the condition is met, output turns ON.
	Latch		Once the condition is met, output keeps ON. *Turns OFF by comparative output reset.
	OneShot 5ms		When the condition is met, output turns ON for 5ms.
	OneShot 10ms		When the condition is met, output turns ON for 10ms.
	OneShot 20ms		When the condition is met, output turns ON for 20ms.
Output Mode [OutputMode]	OneShot 50ms		When the condition is met, output turns ON for 50ms.
	OneShot 0.1s		When the condition is met, output turns ON for 0.1 s.
	OneShot 0.2s		When the condition is met, output turns ON for 0.2s.
	OneShot 0.5s		When the condition is met, output turns ON for 0.5 s.
	OneShot 1s		When the condition is met, output turns ON for 1 s.
	OneShot 2s		When the condition is met, output turns ON for 2s.

This setting variable selects output mode of comparative output.

•Setting steps to set the output mode of **"CompareAL1"** to "OneShot 50ms" are shown below. (Same steps could be applied to AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " CompareAL1 " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "OutputMode" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "OneShot 50ms". *Select a desired mode for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not sto

9 - 5 - 1 - 9. Set Output Logic of Comparative Output

3rd layer Initial 4th layer (Setting Meanings of setting values (Setting values) value variable) When comparative output is ON, Positive (NC) transistor is OFF (1 level). Relay OFF (relay output product) Output Logic (OutputLogic) When comparative output is ON, * Negative (NO) transistor is ON (0 level). Relay ON (relay output product)

This setting variable selects output logic of comparative output.

The above explanation is described with reference to NPN Open collector output. In the case of PNP outputs, the output turns 1 level at transistor ON and turns 0 level at transistor OFF.

In other words, the output logic is reversed on PNP output.

•Setting steps to set output logic of comparative output AL1 to "Positive" are shown below. (Same steps could be applied to AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "CompareAL1" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputLogic " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . * In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Positive Logic". *Select a desired logic for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 1 - 1 0. Set Background Color at Comparative Output ON State

This setting variable selects background color of display when comparative output is ON.

This setting is for the color of background, not for color of characters. The color of characters can be changed and its color is white in measurement display.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	Black	*	Background color is still black when comparative output is ON.
Background Color at ON	Red		Background color turns red when comparative output is ON.
[OnBgColors]	Yellow		Background color turns yellow when comparative output is ON.
	Green		Background color turns green when comparative output is ON.

•Setting steps to set background color of comparative output AL1 to "Red" are shown below. (Same steps could be applied to AL2-AL4.)

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "CompareAL1" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OnBgColors " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Red". *Select a desired color for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 2. ANALOG OUTPUT

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select (PatternSelect)	page83
Select output range of analog output	Output range (OutputRange)	page 84
Select displayable source item for analog output	Source Output display value (OutputDispValue)	page 85
Set scaling of analog output	Output scale (OutputScale)	page 86

Setting variables about analog output appear on models with analog output (WPMZ-5-***- 1^{*-***}).

9 - 5 - 2 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings, output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

CAUTION The pattern number is common to input settings, output settings and display settings.

 Λ

Design contents related to "Analog Output" are registered in the pattern number selected.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	Pattern1		Performs a configuration to pattern No.1
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2
	Pattern3		Performs a configuration to pattern No.3
Pattern select	Pattern4		Performs a configuration to pattern No.4
[Pattern Select]	Pattern5		Performs a configuration to pattern No.5
	Pattern6		Performs a configuration to pattern No.6
	Pattern7		Performs a configuration to pattern No.7
	Pattern8		Performs a configuration to pattern No.8


• Setting steps to set pattern number for analog output to "Pattern8" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "AnalogOutput" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PatternSelect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select the pattern number which you need to be configured.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not stor

mey, the selected contents are not stored. <u>II the power is shut</u>

9 - 5 - 2 - 2. Select Output Range of Analog Output

This setting variable selects the output range of the analog output.



3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	DC0-10V	*	Analog output range: DC0 to 10V Load resistance: more than $2k\Omega$
Output range [OutputRange]	DC±10V		Analog output range: DC-10 to $10V$ Load resistance: more than $2k\Omega$
	DC1-5V		Analog output range: DC1 to 5V Load resistance: more than $2k\Omega$
	DC0-20mA		Analog output range: DC0 to 20mA Load resistance: less than 550Ω
	DC4-20mA		Analog output range: DC4 to 20mA Load resistance: less than 550Ω

• Setting steps to set output range of analog output to "DC1-5V" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "AnalogOutput" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputRange " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "DC1-5V" *Select a desired output range for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display. :If the power is shut down before being pushed the "MENU" key, the selected contents are not st

red. · 🗕

9 - 5 - 2 - 3. Select Displayable Source Item for Analog Output

Because multiple items are selectable for the analog output, an item to use as the analog output should be selected by this setting variable.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No analog output.
Source output	Instantaneous value A (InsA)		Analog output outputs for instantaneous value of chA
display value (OutputDispValue)	Instantaneous value B (InsB)		Analog output outputs for instantaneous value of chB *Displayed in the option with chB input only.
	Instantaneous calculated value (InsCalc)		Analog output outputs for instantaneous calculated value of chA and chB. *Displayed in the option with chB input only.

• Setting steps to set "Source output display value (OutputDispValue)" of the analog output to "Instantaneous value A (InsA)" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "AnalogOutput" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "OutputDispValue" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "InsA". *Select a desired source item for analog output in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 2 - 4. Set Scaling of Analog Output

This setting variable set scaling for analog output.


3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
Output scale	0% display value ±999999	+000000	Set display value when analog output outputs 0% of full scale.
(OutputScale)	100% display value ±999999	+010000	Set display value when analog output outputs 100% of full scale.

[Setting example of scaling]

For the instantaneous value of chA input of 0 to 50000, outputs 4 to 20mA on the analog outputs.

3rd layer (Setting variables)	4th layer (Setting values)	Descriptions for the setting examples	
Output range (OutputRange)	DC4-20mA	To output by "4-20mA" range, the setting variable "output range" should be selected to "DC4-20mA".	
Source output display value (OutputDispValue) Instantaneous value A (InsA)		To output the instantaneous value of chA on the analog output, the setting variable "Source output display value" should be selected to "Instantaneous value A".	
Output scale	(0% display value) +000000	When the instantaneous value is "0", to output 4mA on the analog output, sets "0% display value" to "+000000".	
(OutputScale)	(100% display value) +050000	When the instantaneous value is "50000", to output 20mA on the analog output, sets "100% display value" to "+050000".	

• A setting method of the "output scale" is shown on the following chart.



9 - 5 - 3. BCD OUTPUT

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select (PatternSelect)	page88
Select displayable source item for analog output	OutputDispValue (OutputDispValue)	page 89
Select output logic of data signals.	Data signal logic (DataSignalLogic)	page 90
Select output logic of synchronous signal.	Synchronous signal logic (SyncSignalLogic)	page 91

The setting variables for BCD OUTPUT are shown on the models with BCD output option (WPMZ-5-***- $2 \text{ or } 3^{*-***}$) only.

9 - 5 - 3 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, analog input A/B, 2 input calculations), output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings.

Design contents related to "BCD Output" are registered in the pattern number selected.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	Pattern1		Performs a configuration to pattern No.1
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2
Pattern select	Pattern3		Performs a configuration to pattern No.3
	Pattern4		Performs a configuration to pattern No.4
	Pattern5		Performs a configuration to pattern No.5
	Pattern6		Performs a configuration to pattern No.6
	Pattern7		Performs a configuration to pattern No.7
	Pattern8		Performs a configuration to pattern No.8

• Setting steps to set pattern number for BCD Output to "Pattern8" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "BCD Output" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PatternSelect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select the pattern number which you need to be configured.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not store

9 - 5 - 3 - 2. Select Displayable Source Item for BCD Output

Because multiple items are selectable for the BCD output, an item to use as the BCD output should be selected by this setting variable.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No BCD output
Source output display value (OutputDispValue)	Instantaneous value A (InsA)		BCD output outputs for instantaneous value of chA
	Instantaneous value B (InsB)		BCD output outputs for instantaneous value of chB *Displayed in the option with chB input only.
()	Instantaneous calculated value (InsCalc)		BCD output outputs for instantaneous calculated value of chA and chB. *Displayed in the option with chB input only.

• Setting steps to set "Source output display value (OutputDispValue)" of the BCD output to "Instantaneous value A (InsA)" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "BCD Output" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputDispValue " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "InsA". *Select a desired source item for the BCD output in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing "ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not stor

9 - 5 - 3 - 3. Select Output Logic of BCD Data Signals

This setting variable selects the output logic of the BCD data signals.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
Output Logic	Positive		When data output is ON, transistor is OFF (1 level)
(OutputLogic)	Negative	*	When data output is ON, transistor is ON (0 level)

The above explanation is described with reference to NPN Open collector output. In the case of PNP outputs, the output turns 1 level at transistor ON and turns 0 level at transistor OFF. In other words, the output logic is reversed on PNP output.

•Setting steps to set output logic of BCD data to "Positive" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "BCD Output" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "DataSignalLogic" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Positive" . *Select a desired logic for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 3 - 4. Select Output Logic of BCD Data Synchronous Signal

This setting variable selects the output logic of the BCD data signals.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
Output Logic	Positive		When synchronous output is ON, transistor is OFF (1 level)
(OutputLogic)	Negative	*	When synchronous output is ON, transistor is ON (0 level)

To acquire BCD data, if the synchronous signal (PC) is negative, use the off-state of transistor (i.e. the leading edge or 1 level of PC).

If synchronous signal (PC) is positive, use the on-state of transistor (i.e. the trailing edge or 0 level of PC).

*This explanation is described with reference to NPN Open collector output.

In the case of PNP outputs, the polarity of the output is opposite.

•Setting steps to set output logic of synchronized signal (PC) to "Negative" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "BCD Output" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " SyncSignalLogic " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Negative". *Select a desired logic for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 4. RS-232C COMMUNICATION

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select protocol	Protocol	page91
Select baud rate	Baudrate	page93
Select data length	Datalength	page 94
Select parity bit	Parity	page 95
Select stop bit	Stopbit	page 96
Select delimiter	Delimiter	page 97

The setting variables for RS-232C communication appear only on models with RS-232C option(WPMZ-5-***-4*-***).

9 - 5 - 4 - 1. Select Protocol

This setting variable selects the protocol of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	Modbus-RTU	*	-
Protocol	OriginalComma nd		-
	OriginalOutput		-

•Setting steps to set the protocol of RS-232C to "OriginalCommand" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "RS-232C Com" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Protocol " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "OriginalCommand". *Select a desired baud rate for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	If the power is shut down before being pushed the "MENU" key, the selected contents are not stor

9 - 5 - 4 - 2. Select Baud Rate

This setting variable selects the baud rate of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	9600bps		Baud rate 9600bps
Baudrate	19200bps	*	Baud rate 19200bps
	38400bps		Baud rate 38400bps

•Setting steps to set the baud rate of RS-232C to "38400bps" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "RS-232C Com" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Baudrate " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "38400 bps". *Select a desired baud rate for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
Ø	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

Note: If the power is shut down before being pushed the "MENU" key, the selected contents are not stored.

9 - 5 - 4 - 3. Select Data Length

This setting variable selects the data length of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
Detalesset	7bit	*	Data bit length 7 bit
Datalength	8bit		Data bit length 8 bit

•Setting steps to set the data length of RS-232C to "8bit" are shown below.

No.	Descriptions
	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "RS-232C Com" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " DataLength " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . * In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "8bit". *Select a desired bit length for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 4 - 4. Select Parity Bit

This setting variable selects the parity bit of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	None		No parity bit
Parity	Even	*	Even parity: count of 1's in the data is even
	Odd		Odd parity: count of 1's in the data is odd

•Setting steps to set parity of RS-232C to "Odd" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "RS-232C Com" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Parity " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Odd". *Select a desired parity for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 4 - 5. Select Stop Bit

This setting variable selects the stop bit of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
G(1.1)	1bit	*	Stop bit: 1bit
Stop bit	2bit		Stop bit: 2bit

•Setting steps to set stop bit of RS-232C communication to "2bit" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "RS-232C Com" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Stopbit " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2bit". *Select a desired stop bit for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 4 - 6. Select Delimiter

This setting variable selects the delimiter of RS-232C communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
Dell'action	\mathbf{CR}		Delimiter: CR
Delimiter	CR LF	*	Delimiter: CR. LF

•Setting steps to set delimiter of RS-232C communication to "CR" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "RS-232C Com" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Delimiter " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "CR". *Select a desired delimiter type for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 5. MODBUS COMMUNICATION

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select device address	SlaveAddress	page99
Select baud rate	Baudrate	page 100
Select parity bit	Parity	page 101

The setting variables for Modbus communication appear only on models with Modbus communication option (WPMZ-5-***-5*-***)

9 - 5 - 5 - 1. Select Device Address

This setting variable selects a device address (slave address) of Modbus communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	1	*	Device ID 1
	2		Device ID 2
	3		Device ID 3
	4		Device ID 4
	5		Device ID 5
	6		Device ID 6
	7		Device ID 7
	8		Device ID 8
Γ	9		Device ID 9
	10		Device ID 10
Γ	11		Device ID 11
	12		Device ID 12
	13		Device ID 13
	14		Device ID 14
CI	15		Device ID 15
Slave Address	16		Device ID 16
Address	17		Device ID 17
	18		Device ID 18
	19		Device ID 19
Γ	20		Device ID 20
	21		Device ID 21
Γ	22		Device ID 22
Γ	23		Device ID 23
Γ	24		Device ID 24
Γ Γ	25		Device ID 25
	26		Device ID 26
Γ Γ	27		Device ID 27
	28		Device ID 28
F F	29		Device ID 29
	30		Device ID 30
	31		Device ID 31

•Setting steps to set device ID (Slave address) of Modbus communication "10" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "ModbusCom" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " SlaveAddress " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "10". *Select a desired device Delimiter type for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	: If the power is shut down before being pushed the "MENU" key, the selected contents are not store

9 - 5 - 5 - 2. Select Baud Rate

This setting variable selects the baud rate of Modbus communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	9600bps		Baud rate 9600bps
Baudrate	19200bps	*	Baud rate 19200bps
	38400bps		Baud rate 38400bps

•Setting steps to set the baud rate of Modbus to "38400bps" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "2. Output" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "ModbusCom" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Baudrate " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "38400 bps" . *Select a desired baud rate for your use in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 5 - 5 - 3. Select Parity Bit

This setting variable selects the parity bit of Modbus communication.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	None		No parity bit
Parity	Even	*	Even parity: count of 1's in the data is even
	Odd		Odd parity: count of 1's in the data is odd

•Setting steps to set parity of Modbus to "Odd" are shown below.

No.	Descriptions			
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .			
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "2. Output" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).			
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "ModbusCom" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).			
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Parity " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.			
9	9 By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Odd" . *Select a desired parity for your use in actually.			
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.			
7	D By pushing the "MENU" key, the selected contents are stored and display returns measurement display.			

9-6. DETAIL OF DISPLAY SETTING GROUP

The display setting group is classified to the following small 3 categories and can be configured respectively.

2nd layer (Small categories)	Descriptions	Remarks
Display Select	Select the measurement screen to be displayed during measurement.	Display styles : numerical value display, level display and trend display
Level Display	Sets scales of level display.	
Trend Display	Sets scales of trend display.	

9 - 6 - 1. DISPLAY SELECT

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Selects contents to display on numerical value display from displayable items.	MeasureSelect	page102
Selects contents to display on level display from displayable items.	LevelSelect	page 105
Selects contents to display on trend display from displayable items.	TrendSelact	page106

Note: In each display style, multiple selections are available. All selected display patterns are switched by DISP key or "Monitor Change" functions of the external control input.

9 - 6 - 1 - 1. Select Measurement Display Contents Displayed in Measurement Mode

This product can display multiple items from measured values or calculated values (i.e. displayable source items) on each measurement display style (i.e. numerical value display, level display and trend display). Therefore, by using this setting variable, contents to be shown on each display style should be selected. Each display patterns can be switched by "DISP" key or "pattern change" function of the external control input.

Note: Displayable source items are also used for each output (i.e. comparative outputs, pulse outputs, analog output).

Initial values of display screens are different from 1. Input (without chB input) and 2 inputs (with chB input).

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
Display Select	Instantaneous value A (InsA)	*	Display Instantaneous value of chA input.
(DisplaySel ect)	InsA + Comp		Displays instantaneous value of chA input, comparison judgement values and result.

o1. Input (without chB input) models (WPMZ-5-***PX**-**-***, WPMZ-5-***LX**-**-***)

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	Instantaneous value A (InsA)		Displays Instantaneous value of chA input.
	Instantaneous value B (InsB)		Displays Instantaneous value of chB input.
	Instantaneous value calculation (InsCalc)		Displays calculation result of chA input instantaneous value and chB input instantaneous value.
Display	Instantaneous value A + Instantaneous value B (InsA+InsB)	*	Displays 2 items of chA input instantaneous value and chB input instantaneous value.
Select (DisplaySel ect)	Instantaneous value calculation+ Instantaneous value A + Instantaneous value B (InsCalc+A+B)		Displays 3 items of instantaneous value calculation result, chA input instantaneous value and chB input instantaneous value.
	InsA + Comp		Displays instantaneous value of chA input, comparison judgement values and result.
	InsB + Comp		Displays instantaneous value of chB input, comparison judgement values and result.
	InsCalc + Comp		Displays calculation result value of instantaneous values, comparison judgement values and result.

o2-input (with chB input) models (WPMZ-5-***PP**-**-***, WPMZ-5-***LL****-***)

•In the "Display Select" configuration of a two-inputs model, setting steps that select "Instantaneous value calculation+ Instantaneous value A + Instantaneous value B(InsCulc+A+B)" and does not show default setting "Instantaneous value A + Instantaneous value B (InsA+InsB)" are shown below.



9 - 6 - 1 - 2. Selects Displayable Items to Display on Level Display

This setting variable selects displayed items on level display from displayable items. Each display can be switched by "DISP" key or "pattern change" function of the external control input.

Initial values of display screens are different in the case of 1. Input (without chB input) and in the case of 2 inputs (with chB input).

In level display, 3-item display is not available even for 2 inputs.

o1. Input (without chB input) models (WPMZ-5-***PX**-**-***, WPMZ-5-***LX**-**-***)

3rd layer (Setting variables	4th layer	Initial value	Meaning of setting value
Level Sele	t Instantaneous value A [InsA]	*	Display Instantaneous value of chA input.

o2-input (with chB input) models (WPMZ-5-***PP**-**-***, WPMZ-5-***LL**-**-***)

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	Instantaneous value A [InsA]		Displays Instantaneous value of chA input.
Level select	Instantaneous value B [InsB]		Displays Instantaneous value of chB input.
	Instantaneous value calculation [InsCalc]		Displays calculation result of chA input instantaneous value and chB input instantaneous value.
	Instantaneous value A + Instantaneous value B [InsA+InsB]	*	Displays 2 items of chA input instantaneous value and chB input instantaneous value.

• The setting method is same as that of "Display Select". Refer to "9-6-1-1. Select measurement display contents displayed in measurement mode"

9 - 6 - 1 - 3. Selects Displayable Items to Display on Trend Display

This setting variable selects displayed items on level display from displayable items Each display can be switched by "DISP" key or "pattern change" function of the external control input.

Initial values of display screens are different in the case of 1. Input (without chB input) and in the case of 2 inputs (with chB input).

In trend display, 3-item display is not available even for 2 inputs.

o1. Input (without chB input) models (WPMZ-5-***PX**-**-***, WPMZ-5-***LX**-**-***)

3rd layer (Setting variables)		4th layer (Setting values)	Initial value	Meaning of setting value	
Trend	select	Instantaneous value A [InsA]	*	Displays Instantaneous value of chA input.	

o2-input (with chB input) models (WPMZ-5-***PP**-**-***, WPMZ-5-***LL**-**-***)

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value	
	Instantaneous value A [InsA]		Displays Instantaneous value of chA input.	
	Instantaneous value B [InsB]		Displays Instantaneous value of chB input.	
Trend select	Instantaneous value calculation [InsCalc]		Displays calculation result of chA input instantaneous value and chB input instantaneous value.	
	Instantaneous value A + Instantaneous value B [InsA+InsB]	*	Displays 2 items of chA input instantaneous value and chB input instantaneous value.	

Two phase (90deg phase) pulse inputs are acceptable on pulse 2-input models (WPMZ-5-*PP-**-***). In the case that two-phase is selected as input type and chB or calculated result are selected in Display Select, measurement display shows "-----".

•The setting method is same as that of "Display Select". Refer to "9-6-1-1. Select measurement display contents displayed in measurement mode"

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure settings	Pattern select (PatternSelect)	page108
Set scales of level display for instantaneous value.	Instantaneous value A scale (InsA Scale) Instantaneous value B scale (InsB Scale) Instantaneous value calculation scale (InsCalc Scale)	page109

9 - 6 - 2. LEVEL DISPLAY

9 - 6 - 2 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings, output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings.

Design contents related to "Level Display" are registered in the pattern number selected.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	Pattern1		Performs a configuration to pattern No.1
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2
Pattern select	Pattern3		Performs a configuration to pattern No.3
	Pattern4		Performs a configuration to pattern No.4
	Pattern5		Performs a configuration to pattern No.5
	Pattern6		Performs a configuration to pattern No.6
	Pattern7		Performs a configuration to pattern No.7
	Pattern8		Performs a configuration to pattern No.8

• Setting steps to set pattern number for Level Display to "Pattern8" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "3. Display" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "LevelDisp" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PatternSelect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . * In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select the pattern number which you need to be configured in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Mat	- TC / L

9 - 6 - 2 - 2. Set Scales of Level Display for Instantaneous Value

These setting variables set display scales (display range) of level display (bar graph display) for instantaneous value of inputs.

The range between scale lower limit and scale upper limit is displayed on level display as a bar graph.

These setting variables set scales (display range) of level display only. Scaling settings for instantaneous values are not performed by these setting variables. Instantaneous value B scale (InsB Scale) and instantaneous value calculation scale (IncCalc Scale) appears on models with 2-inputs (with chB).

3rd layer (Setting variables)	4th layer (Setting values)	Initial values	Meanings of setting values	
Instantaneous	scale lower limit ± 999999 +000000		Set lower limit value of level display for chA instantaneous values. Left edge is lower limit of scale.	
value A scale	scale upper limit ±999999	+010000	Set upper limit value of level display for chA instantaneous values. Right edge is upper limit of scale.	
Instantaneous	scale lower limit ±999999	± 000000 instantaneous values		
value B scale	scale upper limit ±999999	+010000	Set upper limit value of level display for chB instantaneous values. Right edge is upper limit of scale.	
Instantaneous calculation	scale lower limit ±999999	+000000	Set lower limit value of level display for instantaneous calculated values. Left edge is lower limit of scale.	
value scale	scale upper limit ±999999	+010000	Set upper limit value of level display for instantaneous calculated values. Right edge is upper limit of scale.	

•In the level display, setting steps to set upper limit value for chA instantaneous values to "5000" are shown below. Same steps can be applied to lower limit value, chB instantaneous value and instantaneous calculation value.



WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Select a pattern number to configure	Pattern select	page111
settings	(PatternSelect) Instantaneous value A	10
	scale (InsA Scale)	
Set scales of trend display for instantaneous value.	Instantaneous value B scale (InsB Scale)	page112
	Instantaneous value calculation scale (InsCalc Scale)	
Set time axis for trend display	Time axis (TimeAxis)	pgae113

9 - 6 - 3. TREND DISPLAY

9 - 6 - 3 - 1. Select a Pattern Number to Configure Settings

This product can memorize 8 patterns (8 kinds) of parameters including input settings, output settings and display settings.

In measurement mode, the product calculates using one of 8 patterns which are configured. This setting selects the pattern number which a configuration is performed.

The pattern number is common to input settings, output settings and display settings.

Design contents related to "Trend Display" are registered in the pattern number selected.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meaning of setting value
	Pattern1		Performs a configuration to pattern No.1
	Pattern2	Pattern number which is selected in measurement mode.	Performs a configuration to pattern No.2
Pattern select	Pattern3		Performs a configuration to pattern No.3
	Pattern4		Performs a configuration to pattern No.4
	Pattern5		Performs a configuration to pattern No.5
	Pattern6		Performs a configuration to pattern No.6
	Pattern7		Performs a configuration to pattern No.7
	Pattern8		Performs a configuration to pattern No.8

• Setting steps to set pattern number for trend display to "Pattern8" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "3. Display" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "TrendDisp" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PatternSelect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Pattern8" * Select the pattern number which you need to be configured in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.
Note	e: If the power is shut down before being pushed the "MENU" key, the selected contents are not store

9 - 6 - 3 - 2. Set Scales of Trend Display for Instantaneous Value


These setting variables set display scales (display range) of trend display for instantaneous value of inputs.

The range between scale lower limit and scale upper limit is displayed on trend display.

- •These setting variables set scales (display range) of trend display only. Scaling settings for instantaneous values are not performed by these setting variables.
- •When the scale is modified, the trend display is redrawn using current value right after the modification and starting with the right end.
- o"Instantaneous value B scale (InsB Scale)" and "Instantaneous value calculation scale (InsCalc Scale)" appear on models with 2 inputs (with chB).

3rd layer (Setting variables)	4th layer (Setting values)	Initial values	Meanings of setting values
Instantaneous	scale lower limit ±9999999 +000000		Set lower limit value of trend display for chA instantaneous values. Lower edge is lower limit of scale.
value A scale	scale upper limit ±999999	+010000	Set upper limit value of trend display for chA instantaneous values. Upper edge is upper limit of scale.
Instantaneous value B scale	scale lower limit ±999999 +000000 Set lower limit value of trend display for instantaneous values. Lower edge is lower limit of scale.		
	scale upper limit ±999999	+010000	Set upper limit value of trend display for chB instantaneous values. Upper edge is upper limit of scale.
Instantaneous calculation value scale	scale lower limit ± 9999999 ± 000000		Set lower limit value of trend display for instantaneous calculated values. Lower edge is lower limit of scale.
	scale upper limit ±999999	+010000	Set upper limit value of trend display for instantaneous calculated values. Upper edge is upper limit of scale.

•In the trend display, setting steps to set upper limit value for chA instantaneous values to "5000" are shown below. Same steps can be applied to lower limit value, chB instantaneous value and instantaneous calculation value.



9 - 6 - 3 - 3. Set Time Axis for Trend Display

This setting variable sets the time axis of trend display.

When the time axis is modified, the trend display is redrawn using current value right after the modification and starting with the right end.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	1s/div	 1 division of time axis is equivalent to 1 second (Maximum display time) Horizontal display: 0.5min, Vertical display: 0 	
	2s/div		1 division of time axis is equivalent to 2 seconds. (Maximum display time) Horizontal display: 0.9min,Vertical display: 0.7min
Time axis (Time Axis)	5s/div		1 division of time axis is equivalent to 5 seconds. (Maximum display time) Horizontal display: 2.3min,Vertical display: 1.7min
	10s/div		1 division of time axis is equivalent to 10 seconds. (Maximum display time) Horizontal display: 4.7min,Vertical display: 3.3min
	30s/div		1 division of time axis is equivalent to 30 seconds. (Maximum display time) Horizontal display: 14min,Vertical display: 10min
	60s/div		1 division of time axis is equivalent to 60 seconds. (Maximum display time) Horizontal display: 28min,Vertical display: 20min
	120s/div		1 division of time axis is equivalent to 120 seconds. (Maximum display time) Horizontal display: 56min,Vertical display: 40min

•Setting steps to set the time axis of trend display to "30s/div" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "3. Display" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories).
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "TrendDisp" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " TimeAxis " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "30s/div" * Select the time axis which you need to be configured in actually.
6	By pushing "ENTER" key, a message "Changing the time axis, trend data will be cleared" appears and the cursor is placed on "Cancel"
7	By moving the cursor with " ARROW (UP/DOWN) " keys, point the cursor to " OK ". Push " ENTER " key, then the setting becomes valid and the check mark moves to "30s/div". *If the setting is needed to cancel, move the cursor to " CANCEL "and push " ENTER " key.
8	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9-7. DETAIL OF SYSTEM SETTING GROUP

The system setting group is classified to the following small 2 categories and can be configured respectively.

2nd layer (Small categories)	Descriptions	Remarks
General	Configure setting of supporting functions, such as brightness of display	
Initialize	Configure setting about initialization.	

9 - 7 - 1. GENERAL

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Change brightness of display	Brightness	page 115
Delay start up time	PowerOnDelay	page 116
Set power saving time	PowerSavingTime	page 117
Change displayed language	Language	page 118
Change direction of display	DisplayDirecton	page 119
Protect settings	SettingProtect	page 120
Copy data of a pattern number to other pattern number(s).	PatternCopy	page 121

9 - 7 - 1 - 1. Change Brightness of Display

By this setting variable, the brightness of display can be controlled by 6 steps.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	5 Bright	*	Bright
	4		Rather dark
Brightness	3		Dark
	2		Very dark
	1 Dark		Darkest
	0 Off		Light off

If "0 Off (Light off)" is set, whole of display turns light off and goes black. In this case, display lights up by pushing MENU key and FUNC key.

•Setting steps to set brightness of disp	blay to "1 Dark "are shown below.
--	-----------------------------------

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "4. System" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "General" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Brightness " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "1 Dark". *Select a desired brightness in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 7 - 1 - 2. Provide Wait Time after Power on

This setting variable provides waiting time after power on to start measurement.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	None	*	No waiting time
	2sec		Waiting time 2sec
PowerOn Delay	5 sec		Waiting time 5sec
	10 sec		Waiting time 10sec
	20 sec		Waiting time 20sec
	30 sec		Waiting time 30sec
	60 sec		Waiting time 60sec

◦In the power on delay period, the display indicates "-----". ◦While "-----"is displayed, all outputs keep OFF state.

•Setting steps to set "Power on delay" to "10sec"are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "4. System" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "General" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " PowerOnDelay " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "10sec" . *Select a desired time in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 7 - 1 - 3. Set Power Saving Time

This setting variable sets time of power saving mode.

After no key operation over the time, the display turns power saving mode automatically. During power saving display, if any key is pushed, the power saving mode is released.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	None	*	No power saving display.
	1min		After 1minute of no key operation, display turns power saving display.
	2min		After 2minutes of no key operation, display turns power saving display.
Power saving time [PowerSavingTime]	5min		After 5minutes of no key operation, display turns power saving display.
	10min		After 10minutes of no key operation, display turns power saving display.
	30min		After 30minutes of no key operation, display turns power saving display.
	60min		After 60minutes of no key operation, display turns power saving display.

In "Power saving display" mode, the brightness of the display is "1 dark".

•Setting steps to set "PowerSavingTime" to "5min"are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "4. System" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "General" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "PowerSavingTime" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents). *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "5min". *Select a desired time for power saving in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.


9 - 7 - 1 - 4. Select Displayed Language

This setting variable selects language displayed in measurement mode and setting mode.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Tanana	日本語	*	Displayed in Japanese.
Language	English		Displayed in English.

•Setting steps to set language from "日本語" to "English" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "4. システム設定" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "全般" and push "ARROW (RIGHT)" key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "言語" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "English". *Select a desired language in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.



9 - 7 - 1 - 5. Change Direction of Display

This setting variable selects direction of display in measurement mode and setting mode.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
Direction of display	Horizontal	*	Horizontal display.
(DisplayDirection)	Vertical		Vertical display.

If you change direction of display, measurement values are cleared and measurement restarts. Functions of Arrow keys (UP/DOWN/LEFT/RIGHT) are adapted to the direction of display.

•Setting steps to set direction of display to "Vertical" are shown below.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "4. System" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "General" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " DisplayDirection " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Vertical" . *Select a desired direction in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 7 - 1 - 6. Protect Settings

By this setting variable, settings which have been configured can be protected to prevent further change in setting mode.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
Setting protect	Disable	*	Protection of settings is disabled.
(SettingProtect)	Enable		Protection of settings is enabled.

When setting protection is enabled, you can see setting values which are configured, but you cannot change them. If you need to change them, let setting protect to disable in advance.

•Setting steps to set "Setting protect" to "Enable" are shown below.


No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "4. System" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "General" and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " SettingProtect " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer (setting contents) . *In the 4th layer, the currently selected parameter accompanies a check mark.
5	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "Enable". *Select a desired setting in actually.
6	Pushing "ENTER" key, selected parameters become valid and a check mark accompanies. *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
$\overline{\mathcal{O}}$	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 7 - 1 - 7. Copy Configured Pattern Data to Other Patterns

Using this setting variable, you can copy a configured pattern data on some pattern number to other pattern number(s).

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values	
	(Copy from) [Source pattern number]			
	Pattern1	*	Copy data of Pattern 1 to destination pattern No.	
	Pattern2		Copy data of Pattern 2 to destination pattern No.	
	Pattern3		Copy data of Pattern 3 to destination pattern No.	
	Pattern4		Copy data of Pattern 4 to destination pattern No.	
	Pattern5		Copy data of Pattern 5 to destination pattern No.	
	Pattern6		Copy data of Pattern 6 to destination pattern No.	
	Pattern7		Copy data of Pattern 7 to destination pattern No.	
	Pattern8		Copy data of Pattern 8 to destination pattern No.	
	(Copy to) [Destin	nation pattern nur	nber]	
Pattern	Pattern1		Copy data of source pattern No to Pattern 1.	
copy	Pattern2		Copy data of source pattern No to Pattern 2.	
	Pattern3		Copy data of source pattern No to Pattern 3.	
	Pattern4		Copy data of source pattern No to Pattern 4.	
	Pattern5		Copy data of source pattern No to Pattern 5.	
	Pattern6		Copy data of source pattern No to Pattern 6.	
	Pattern7		Copy data of source pattern No to Pattern 7.	
	Pattern8		Copy data of source pattern No to Pattern 8.	
	All patterns	*	Copy data of source pattern No to All pattern No.	
	(Operation Select	ts)		
	Cancel	*	Cancel pattern copy	
	Execute		Execute pattern copy	

When setting protects is enabled, you can see setting values which are configured, but you cannot change them. If you need to change them, let setting protect to disable in advance. •Setting steps to copy configured data of pattern 2 to all pattern numbers are shown below.



9 - 7 - 2. INITIALIZATION

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Restore setting values to user default	Save user defaults (UserDefaultSave)	page123
value.	Initialize to user defaults (UserDefaultLoad)	page123
Restore setting values to factory default value	Initialize to factory defaults (FactoryDefaultLoad)	page124

9 - 7 - 2 - 1. Restore Setting Values to User Default Value (Save User Defaults)

Using this setting variable, you can save setting values you have configured as user default values and can initialize to these saved values. First, registering user default values are needed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meaning of setting value	
	Save current settings as user initial values?			
Save user defaults (UserDefaultSave)	Yes		Execute saving to register.	
	No	*	Cancel saving to register.	

To save user default values, setting values must be configured to values which are used as initial values.

•The operation for registering user default values is same as the case of "initialize to factory defaults". Refer to "9-7-2-3. Restore setting values to factory default value".

9 - 7 - 2 - 2. Restore Setting Values to User Default Value (Initialize to User Defaults)

Using this setting variable, setting values can be restored to user default values.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values		
Initialize to user	Initialize setting values to user initial values?				
defaults	Yes		Execute initialization.		
(UserDefaultLoad)	No	*	Cancel initialization.		


•The operation for registering user default values is same as the case of "initialize to factory defaults". Refer to "9-7-2-3. Restore setting values to factory default value".

9 - 7 - 2 - 3. Restore Setting Values to Factory Default Value

Using this setting variable, setting values can be restored to factory default values.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values	
Initializa ta factory	Initialize setting values to factory defaults?			
Initialize to factory defaults	Yes		Execute initialization.	
(FactoryDefaultLoad)	No	*	Cancel initialization.	

•To initialize setting values to factory default values perform the following operation.



Note: The setting method of the language is referred to p118

9-8. DETAIL OF INPUT-OUTPUT DIAGNOSIS GROUP

The input-output diagnosis group is classified to the following small 2 categories and can be configured respectively.

2nd layer (Small categories)	Descriptions	Remarks
Input diagnosis	Performs diagnosis for inputs.	
Output test	Outputs "simulated outputs"	

9 - 8 - 1. INPUT DIAGNOSIS

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Dulas innut diamasia	PulseInputA	
Pulse input diagnosis	PulseInputB	page126
External control input diagnosis	ExtenalCtrl	page127


9 - 8 - 1 - 1. Pulse Input Diagnosis

Pulse input diagnosis is useful for checking the pulse inputs when display value is not correct or when existence of sensor outputs is uncertain.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
			No setting value, no initial value
PulseInputA	Number of pulse after entering 4th layer		Entering 4th layer, starts counting pulse immediately.
	InputFrequency		Display current frequency measurement value
_		—	No setting value, no initial value
PulseInputB	Number of pulse after entering 4th layer		Entering 4th layer, starts counting pulse immediately.
	InputFrequency		Display current frequency measurement value

Only WPMZ-5-*PP-**-*** and WPMZ-5-*LL-**-*** is "PulseInputB" appears. In this case, **"PulseInputA"** is for chA input, "PulseInputB" is for chB input.

•To perform the pulse input diagnosis, the following operation is needed. (Same operation can be also applied to the pulse input B.)




9 - 8 - 1 - 2. External Control Input Diagnosis

By External Control Input Diagnosis, the status of external control terminal can be monitored.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	(terminal 1)		
	Current status	OFF	Displays current status in "OFF" or "ON".
	(terminal 2)		
External	Current status	OFF	Displays current status in "OFF" or "ON".
Control	(terminal 3)		
Inputs (ExternalCt	Current status	OFF	Displays current status in "OFF" or "ON".
rl)	(terminal 4)		
	Current status	OFF	Displays current status in "OFF" or "ON".
	(terminal 5)		
	Current status	OFF	Displays current status in "OFF" or "ON".

•To perform the external control input diagnosis, the following operation is needed.



9 - 8 - 2. OUTPUT TEST

WHAT YOU CAN DO	3rd layer (Setting variables)	Reference page
Simulated output on comparative	Comparative output AL1 (Compare AL1) Comparative output AL2 (Compare AL2)	nom120
output	Comparative output AL3 (Compare AL3)	page129
	Comparative output AL4 (Compare AL4)	
Simulated output on analog output	AnalogOutput	page 131
C'un later land and an DCD and and	BCD Output(DATA)	100
Simulated output on BCD output	BCD Output(PC)	page 133
Diagnosis of RS-232C communication	RS-232C Com	page135
Diagnosis of Modbus communication	ModbusCom	page136

9 - 8 - 2 - 1. Simulated Output of Comparative Output

By using simulated output of comparative output, the status of comparative output can be set to "ON" or "OFF" arbitrary. You can test devices connected to comparative outputs in advance.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meanings of setting values
	TestOutput		
	Disable	*	Simulated output is disabled.
Comparative	Enable		Simulated output is enabled.
output AL1 (Compare AL1)	TerminalOutput		
	ON output	*	Terminal state is ON when enabled.
	OFF output		Terminal state is OFF when enabled.
	TestOutput		
	Disable	*	Simulated output is disabled.
Comparative	Enable		Simulated output is enabled.
output AL2 (Compare AL2)	TerminalOutput		
	ON output	*	Terminal state is ON when enabled.
	OFF output		Terminal state is OFF when enabled.
	TestOutput		
	Disable	*	Simulated output is disabled.
Comparative output AL3	Enable		Simulated output is enabled.
(Compare AL3)	TerminalOutput		
	ON output	*	Terminal state is ON when enabled.
	OFF output		Terminal state is OFF when enabled.
	TestOutput		
	Disable	*	Simulated output is disabled.
Comparative output AL4	Enable		Simulated output is enabled.
(Compare AL4)	TerminalOutput		
	ON output	*	Terminal state is ON when enabled.
	OFF output		Terminal state is OFF when enabled.

If simulated output is enabled, output continues until the setting is set to disable or power off.

•To perform the test output of comparative output, the following operation is needed. (Same operation can be also applied to comparative outputs AL2-AL4.)



*To stop simulated output, set "simulated output setting" to "Disable" or turn the power once.

9 - 8 - 2 - 2. Simulated Output of Analog Output


Simulated output of analog output can output 0-100% (10% steps) value of selected output range. You can test devices connected to analog outputs in advance.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values
	TestOutput		
	Disable	*	Simulated output is disabled.
	Enable		Simulated output is enabled.
	TerminalOutput		
	0%	*	Outputs 0 % value of output range.
	10%		Outputs 10 % value of output range.
	20%		Outputs 20 % value of output range.
Analog output (AnalogOutput)	30%		Outputs 30 % value of output range.
C	40%		Outputs 40 % value of output range.
	50%		Outputs 50 % value of output range.
	60%		Outputs 60 % value of output range.
	70%		Outputs 70 % value of output range.
	80%		Outputs 80 % value of output range.
	90%		Outputs 90 % value of output range.
	100%		Outputs 100 % value of output range.

* Once simulated output is enabled, output continues until the setting is set to disable or turning off power of the product.

* This setting variable appears only on models with analog output (WPMZ-5-***-1*-***).

•To perform the test output of analog Output, the following operation is needed. The operation is an example to output 50% value of rating.



* To stop simulated output, set setting to "Disable" or turn off the power of the product.

9 - 8 - 2 - 3. Simulated Output of BCD Output

Simulated output of BCD output can set each bit of BCD to "ON" level or "OFF" level arbitrarily. You can test devices connected to BCD outputs in advance.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values	
	TestOutput			
	Disable	*	Simulated output is disabled.	
	Enable		Simulated output is enabled.	
	POL Output		Output to POL terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	OVER Output		Output to OVER terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	105-1/105-2/105-4/	10 ⁵ -8 Output	Output to 10 ⁵ digit 1/2/4/8bit terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	104-1/104-2/104-4/	104-8 Output	Output to 10 ⁴ digit 1/2/4/8bit terminal	
BCD output (DATA)	OFF output	*	Terminal state is OFF when enabled.	
(271117)	ON output		Terminal state is ON when enabled.	
	103-1/103-2/103-4/	10 ³ -8 Output	Output to 10^3 digit $1/2/4/8$ bit terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	102-1/102-2/102-4/	10 ² -8 Output	Output to 10^2 digit $1/2/4/8$ bit terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	101-1/101-2/101-4/	10 ¹ -8 Output	Output to 10^1 digit $1/2/4/8$ bit terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	100-1/100-2/100-4/	10º-8 Output	Output to 10 ⁰ digit 1/2/4/8bit terminal	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	
	TestOutput			
	Disable	*	Simulated output is disabled.	
BCD output	Enable		Simulated output is enabled.	
(PC)	PC Output		Output to PC terminal.	
	OFF output	*	Terminal state is OFF when enabled.	
	ON output		Terminal state is ON when enabled.	

- Once simulated output is enabled, output continues until the setting is set to disable or turning off power of the product.

- This setting variable appears only on models with BCD output (WPMZ-5-***-2 or 3*-***)

To perform the test output of BCD Output, the following operation is needed. The operation is an example to output POL.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "5. Diagnosis" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputTest " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "BCD Output (DATA)" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer.
5	By moving the cursor with " ARROW (DOWN) " key, point the cursor to " POL Output " and push " ARROW (RIGHT) " key, then the display moves to the 4th layer .
6	By moving the cursor with "ARROW (DOWN)" key, point the cursor to "POL Output" and by pushing "ENTER" key, setting becomes acceptable. And, icon of "ARROW (UP/DOWN)" key appears on left side of the cursor. Using "ARROW (UP/DOWN)" keys, test output is set to "ON output". *Set all bits for outputs desired to be tested to "ON output" or "OFF output" in actually.
Ī	By pushing "ENTER" key, the setting is fixed, the icon of "ARROW (UP/DOWN)" key on left side of the cursor disappears.
8	By moving the cursor with "ARROW (UP)" key, point the cursor to "TestOutput" and push "ENTER" key, then setting is acceptable. And, icon of "ARROW (UP/DOWN)" key appears on left side of the cursor. Using "ARROW (UP/DOWN)" keys, test output is set to "Enable".
9	By pushing " ENTER " key, setting values are fixed and <u>Simulated output start to output</u> . *Pushing " ARROW (LEFT) "key each time, the display returns to the 3rd layer, the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
10	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

Caution: To stop simulated output, set setting to "Disable" or turn off the power of the product.

9 - 8 - 2 - 4. Diagnosis of RS-232C Communication

Diagnosis of RS-232C communication provides monitoring of communication condition. Command sent from host and response to the command is displayed.

3rd layer (Setting variable)	4th layer (Setting values)	Initial value	Meanings of setting values	
	ReceiveData		Displays data sent from host (command)	
RS-232C	—	—	No setting value (No initial value)	
Communica tion	TransmitData		Displays response data	
	_	_	No setting value (No initial value)	

This setting variable appears only on models with RS-232C communication (WPMZ-5-***-4*-***).

•To perform diagnosis of RS-232C communication, the following operation is needed.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to "5. Diagnosis" and push " ARROW (RIGHT) " key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " OutputTest " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "RC-232C Com" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer and diagnosis (communication check) can be done.
5	If Data (command) is sent from host correctly, it is displayed as Receive Data and Response data is displayed as transmit data.
6	Pushing " ARROW (LEFT) "key, the display returns to the 3rd layer and diagnosis of RS-232C is terminated. Pushing " ARROW (LEFT) "key moreover, the display returns to the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
7	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

9 - 8 - 2 - 5. Diagnosis of Modbus Communication

Diagnosis of RS-485 (Modbus) communication, which although belongs to "Output Test" category, allows to monitoring the condition of communication.

Both of received data which is transmitted by the host as command and transmitted data which is transmitted by this product as the response to the command can be displayed.

3rd layer (Setting variables)	4th layer (Setting values)	Initial value	Meaning of setting value
	Received data		Displays data transmitted from the host as command.
Modbus Communication			No setting value (No initial value)
[ModbusCom]	Transmitted dataDisplays data transmitted from this pro- as response.	Displays data transmitted from this product as response.	
	_	_	No setting value (No initial value)

This setting variable appears only on models with Modbus communication function (WPMZ-5-***-5*-***).

• For diagnosis of Modbus communication, perform the following operation.

No.	Descriptions
1	By pushing the " MENU " key in the measurement mode, the display moves to the setting display and shows the 1st layer (major categories) .
2	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "5. Diagnosis" and push "ARROW (RIGHT)" key, then the display moves to the 2nd layer (small categories) .
3	By moving the cursor with " ARROW (UP/DOWN) " key, point the cursor to " Output test " and push " ARROW (RIGHT) " key, then the display moves to the 3rd layer (setting variables).
4	By moving the cursor with "ARROW (UP/DOWN)" key, point the cursor to "ModbusCom" and push "ARROW (RIGHT)" key, then the display moves to the 4th layer and diagnosis (communication check) can be done.
5	If Data (command) is sent from host correctly, it is displayed as Receive Data and Response data is displayed as transmit data.
6	Pushing "ARROW (LEFT)" key, the display returns to the 3rd layer and diagnosis of Modbus is terminated. Pushing "ARROW (LEFT)" key moreover, the display returns to the 2nd layer and 1st layer. If you need other settings, operate required steps continuously.
\bigcirc	By pushing the "MENU" key, the selected contents are stored and display returns the measurement display.

10. CONTROL FUNCTIONS

10-1. EXTERNALCONTROL FUNCTIONS

As external control functions, this product have compare reset function, measurement inhibit function, display hold function, maximum value hold function, minimum value hold function, pattern select function etc., each function can be performed by assigning to external control terminals 1-5.

10-1-1. EXTERNAL CONTROL FUNCTION ICONS

When an EXTERNAL CONTROL FUNCTION is enabled, an ICON for each function lights up.

Icon	Description
P5	Indicates pattern No. in use.
	Indicates the KEY LOCK function is effective.
\odot	Indicates the COMPARATIVE OUTPUT RESET function is effective.
\oslash	Indicates the MEASUREMENT INHIBIT function is effective.
0	Indicates the DISPLAY HOLD function is effective.
	Indicates the MAXIMUM VALUE HOLD function is effective.
	Indicates the MINIMUM VALUE HOLD function is effective.

10-1-2. TERMINAL CONTROL

The control of assigned functions is performed by shorting each terminal to the com terminal or bringing to the "0" level

"0" level: 0 to 1.5V

"1" level: 3.5 to 5V

Input current: -1.2mA

* The control terminals 1 to 5 are isolated from Power and input as DC signals.

10-1-3. COMPARATIVE OUTPUT RESET FUNCTION

Comparative output reset function makes all of comparative judgement results and their outputs OFF.

The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

10-1-4. MEASUREMENT INHIBIT FUNCTION

The measurement inhibit function inhibits the input and the display value accompanies this. This function can be selected from the following 3 kinds.

The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

Measurement inhibit A: inhibits the input of chA

Measurement inhibit B: inhibits the input of chB

Measurement inhibit A&B: inhibits the inputs of both chA and chB

10-1-5. DISPLAY HOLD FUNCTION

Display hold function holds current display value and can be selected from the following 3 kinds. The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

While this function is valid, measurement action is performed internally and the latest measurement value is displayed when the function become invalid.

Display hold A: holds the display of chA

Display hold B: holds the display of chB

Display hold A&B: holds the display of chA and chB

10-1-6. MAXIMUM VALUE HOLD FUNCTION

Maximum value hold function is the function which holds the maximum display value and can be selected from the following 3 kinds.

The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

Maximum hold A: holds the maximum display value of chA

Maximum hold B: holds the maximum display value of chB

Maximum hold A&B: holds the maximum display value of chA and chB

*If the displayed value becomes over while the maximum hold function is valid, over display never disappears until the function is canceled.

Note: This function is valid for the instantaneous value only.

10-1-7. MINIMUM VALUE HOLD FUNCTION

Minimum value hold function is the function which holds the minimum display value and can be selected from the following 3 kinds.

The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

*When both of the maximum value hold and the minimum value hold are ON simultaneously, only the maximum value hold becomes valid.

Minimum hold A: holds the minimum display value of chA

Minimum hold B: holds the minimum display value of chB

Minimum hold A&B: holds the minimum display value of chA and chB

Note: This function is valid for the instantaneous value only and invalid for the totalized value.

10-1-8. PATTERN SELECT FUNCTION

This product can memorize 8 patterns (8 kinds) of parameters including input settings (pulse input A/B, analog input A/B, 2 input calculations), output settings and display settings. By using pattern select 1-3, Up to 8 patterns can be switched.

Function	Selected pattern No. (pattern No. in use)							
Name	1	2	3	4	5	6	7	8
Pattern select1	Open	Short	Open	Short	Open	Short	Open	Short
Pattern select2	Open	Open	Short	Short	Open	Open	Short	Short
Pattern select3	Open	Open	Open	Open	Short	Short	Short	Short

Open: pattern select terminal is open or connected to "1" level.

Short: pattern select terminal is shorted to COM terminal or connected to "0" level.

If the used pattern is switched, measured data is cleared and the measurement restarts from the switched time point.

10 - 1 - 9. MONITOR CHANGE FUNCTION

The monitor change function is the function which switches display.

The display is switched by shortening the terminal, which the function is assigned to, to COM terminal or bringing it to "0" level for over 20ms.

It performs same action of DISP key at front panel.

10-1-10. TREND HOLD FUNCTION

The trend hold function is a function which holds the trend display.

The function becomes valid while the terminal which is assigned the function is shortened to the COM terminal or brought to 0 level.

When the function is disabled, the WPMZ starts plotting the trend display with the current measurement value.

10-2. SHORTCUT FUNCTION

Shortcut function is external control functions are registered to arrow keys and are performed not by the terminal control but by the operation of the keys.

10-2-1. SHORTCUT REGISTER KEYS

Keys which can be registered shortcut functions are shown below.

Keys can be registered shortcut Functions in					
	Up arrow key				
\mathbf{i}	Down arrow key	Used in the shortcut			
≪	Left arrow key	function on measurement display.			
>>>	Right arrow key				


10-2-2. FUNCTIONS CAN BE REGISTERED TO SHORTCUT

Functions which can be registered to shortcut functions are shown below

Function	Action				
None	No function.				
Comparative output reset	et Comparative output reset function makes all of comparative judgement results and their outputs OFF.				
Measurement block A	The measurement inhibit chA is function inhibits the input and the display value accompanies this.				
Measurement block B	The measurement inhibit chB is function inhibits the input and the display value accompanies this.				
Measurement block A&B	The measurement inhibit chA and chB is function inhibits the input and the display value accompanies this.				
Display hold A	Display hold chA function holds display value.				
Display hold B	Display hold chB function holds display value.				
Display hold A&B	Display hold A&B Display hold chA and chB function holds display value.				
Maximum value hold A	hold A Maximum value hold chA function is the function which holds the maximum display value.				
Maximum value hold B	Maximum value hold chB function is the function which holds the maximum display value.				
Maximum value hold A&B	Maximum value hold chA and chB function is the function which holds the maximum display value.				
Minimum value hold A	Minimum value hold chA function is the function which holds the minimum display value.				
Minimum value hold B	Minimum value hold chB function is the function which holds the minimum display value.				
Minimum value hold A&B Minimum value hold chA and chB function is the function which hold minimum display value.					
Pattern select	Pattern select function assigned to 1st bit				
Trend hold	The trend hold function is a function which holds the trend display.				

10-2-3. REGISTERING SHORTCUT FUNCTIONS

Registering shortcuts how to set up is shown below



10-2-4. PERFORMING SHORTCUT FUNCTIONS

A shortcut function is performed by holding down the arrow key which an external control function is registered for 1 second.

An active function becomes inactive by holding down the arrow key which the function is registered for 1 second again.



The icon for active external control lights up

If the external control assigned to the shortcut is registered in the terminal, it can not be controlled with shortcut function.

*Priority of external control is

"RS control"> "control with external control terminal"> "control with arrow keys (shortcut function)".

11. COMPARATIVE OUTPUT FUNCTION

$1 \ 1 - 1$. COMPARATIVE OUTPUT FUNCTION

Comparative output function compares displayed value (including other displayable values) and judgement value which is configured in advance and shows the result on "comparison result" on the display and also outputs the result on comparative output terminals.

Comparative outputs are open-collector outputs which can be selected from NPN type or PNP type by model codes.

As modes of the comparison, 2 modes shown below are available.

Comparison mode	Action
Level judgement	Compares a displayable value to 1 judgement value in magnitude relation.
Zone judgement	Compares a displayable value to 2 judgement values in inclusion relation.

11-1-1. SOURCE DISPLAYABLE VALUE FOR COMPARISON

As comparative outputs, this product has 4 outputs AL1-AL4 which can be configured independently.

To each displayable value, comparative outputs AL1-AL4 can be assigned arbitrarily. For example, you can assign each displayable value to all of AL1-AL4, or else, you can assign the instantaneous value of chA input to AL1, AL2, instantaneous value of chB to AL3, AL4.

Comparative output can be assigned to a displayable item including items which are not displayed on the display. If the condition of comparison is met, "comparison result" is displayed and comparative output is output.

11-1-2. LEVEL JUDGEMENT

In the case that the "level judgement" is selected in compare mode, this product judges magnitude relation to comparison judgement value.

To output comparison result, by configurations for "Condition of ON (OnConditions)", "output mode (OutputMode)" etc., compare action should be determined.


The followings show judgement actions on each output mode in the case that comparative outputs AL1-AL4 are assigned to one displayable item (i.e. source value).

1) Upper judgement of 4 steps


For using in the upper judgement, the setting variable "Condition of ON (OnCondition)" should be configured to "excess".

Comparative output	Condition of ON	Condition of comparison	Judgement result
AL1	ON at "Excess"	Display value >AL1 judgement value	AL1
AL2	ON at "Excess"	Display value >AL2 judgement value	AL2
AL3	ON at "Excess"	Display value >AL3 judgement value	AL3
AL4	ON at "Excess"	Display value >AL4 judgement value	AL4

•Judgement action in the case that output mode is "Normal". Output mode "Normal": comparative output is valid while judgement is ON.




•Judgement action in the case that output mode is "Latch". Output mode "Latch": Comparative output keeps valid once judgement becomes ON.



In Latch mode, reset of comparative output is performed by comparative output reset of external control.

•Judgement action in the case that output mode is "One Shot".

Output mode "One Shot": Comparative output is valid while setup time period after judgement is ON.



2) Upper judgement of 2 steps and lower judgement of 2 steps (HH/HI/LO/LL)


For AL1 and AL2 used in the upper judgement, the setting variable "Condition of ON (OnCondition)" should be configured to "Excess".

Comparative output	Condition of ON	Condition of comparison	Judgement result
AL1	ON at "Excess"	Display value >AL1 judgement value	AL1
AL2	ON at "Excess"	Display value >AL2 judgement value	AL2
AL3	ON at "Less Than"	Display value <al3 judgement="" td="" value<=""><td>AL3</td></al3>	AL3
AL4	ON at "Less Than"	Display value <al4 judgement="" td="" value<=""><td>AL4</td></al4>	AL4


For AL3 and AL4 used in the lower judgement, the setting variable "Condition of ON (OnCondition)" should be configured to "Less Than".

•Judgement action in the case that output mode is "Normal".


Output mode "Normal": comparative output is valid while judgement is ON.



•Judgement action in the case that output mode is "Latch". Output mode "Latch": comparative output keeps valid once judgement becomes ON.



•Judgement action in the case that output mode is "One Shot". Output mode "One Shot": comparative output is valid while setup time period after judgement is ON.




3) Lower judgement of 4 steps

For using in the lower judgement, the setting variable "Condition of ON (OnCondition)" should be configured to "Less Than".


Comparative output	Condition of ON	Condition of comparison	Judgement result
AL1	"Less Than"	Display value <al1 judgement<br="">value</al1>	AL1
AL2	"Less Than"	Display value <al2 judgement<br="">value</al2>	AL2
AL3	"Less Than"	Display value <al3 judgement<br="">value</al3>	AL3
AL4	"Less Than"	Display value <al4 judgement<br="">value</al4>	AL4

•Judgement action in the case that output mode is "Normal".

Output mode "Normal": comparative output is valid while judgement is ON.




Judgement action in the case that output mode is "Latch".
 Output mode "Latch": Comparative output keeps valid once judgement becomes ON.



In Latch mode, reset of comparative output is performed by comparative output reset of external control.

•Judgement action in the case that output mode is "One Shot". Output mode "One Shot": comparative output is valid while setup time period after judgement is ON.



11-1-3. ZONE JUDGEMENT

In the case that the "Zone judgement" is selected in compare mode, this product judges inclusion relation to 2 comparison judgement values.

To output comparison result, by configurations for "Condition of ON (OnConditions)","output mode (OutputMode)" etc. , compare action should be determined.

The followings show judgement actions on each output mode.

Comparative outputs AL1-AL4 can be configured independently and can be assigned to displayable items arbitrary. Therefore, for each comparative output, 2 setting values of the upper limit and the lower limit are required to perform zone judgement.


1) "Condition of ON (OnCondition)" is "In the zone"

When the value of the source item (displayable value) for comparison is between "Zone upper limit" and "Zone lower limit", comparative output result turns ON.


Comparative output	Condition of ON	Condition of comparison	Judgement result
AL1		$AL1$ Zone upper limit \geq Display value $\geq AL1$ Zone lower limit	AL1
AL2	"In the zone"	AL2 Zone upper limit \geq Display value \geq AL2 Zone lower limit	AL2
AL3		AL3 Zone upper limit ≥ Display value ≥AL3 Zone lower limit	AL3
AL4		AL4 Zone upper limit ≥ Display value ≥AL4 Zone lower limit	AL4

Hystereses lie on outside (upper side) of the zone upper limit and outside (lower side) of the zone lower limit. The widths of the hystereses are same on both zone upper limit and zone lower limit.

•Judgement action in the case that output mode is "Normal". Output mode "Normal": comparative output is valid while judgement is ON.




Judgement action in the case that output mode is "Latch".
 Output mode "Latch": Comparative output keeps valid once judgement becomes ON.



In Latch mode, reset of comparative output is performed by comparative output reset of external control.

•Judgement action in the case that output mode is "One Shot". Output mode "One Shot": Comparative output is valid while setup time period after judgement is ON.




2) "Condition of ON (OnCondition)" is "Outside of the zone"

When the value of the source item (displayable value) for comparison is over "Zone upper limit" or under "Zone lower limit", comparative output result turns ON.


Comparative output	Condition of ON	Condition of comparison	Judgement result
AL1	"Outside of the zone"	Display value > AL1 Zone upper limit or AL1 Zone lower limit > Display value	AL1
AL2		Display value > AL2 Zone upper limit or AL2 Zone lower limit > Display value	AL2
AL3		Display value > AL3 Zone upper limit or AL3 Zone lower limit > Display value	AL3
AL4		Display value > AL4 Zone upper limit or AL4 Zone lower limit > Display value	AL4

Hystereses lie on outside (upper side) of the zone upper limit and outside (lower side) of the zone lower limit. The widths of the hystereses are same on both zone upper limit and zone lower limit.

•Judgement action in the case that output mode is "Normal". Output mode "Normal": comparative output is valid while judgement is ON.




Judgement action in the case that output mode is "Latch".
 Output mode "Latch": Comparative output keeps valid once judgement becomes ON.



In Latch mode, reset of comparative output is performed by comparative output reset of external control.

•Judgement action in the case that output mode is "One Shot". Output mode "One Shot": comparative output is valid while setup time period after judgement is ON.



12. OUTPUT FUNCTIONS

12-1. ANALOG OUTPUT FUNCTION

The models with an analog output option can output an analog output for a displayable value. As output ranges, 5 types of 0-10V, \pm 10 V, 1-5V, 0-20mA and 4-20mA are equipped and they can be switched by a setting variable in "Analog Output" in "Output".

12-1-1. SOURCE DISPLAYABLE VALUE FOR OUTPUT

Analog output has one channel and an output source should be selected from various displayable items.

Even if the selected item is not displayed, the output is valid.

12-1-2. ANALOG OUTPUT SCALING

Analog output can be scaled arbitrary. For the scaling, settings of display value for 0% output and display value for 100% for each output range are required.

Output range	0%output value	100%output value
DC0-10V	0V	10V
DC±10V	-10V	10V
DC1-5V	1V	$5\mathrm{V}$
DC0-20mA	0mA	20mA
DC4-20mA	4mA	20mA

12-1-3. OUTPUT RANGE OF ANALOG OUTPUT

Analog output can output in the range of ± 10 % of full scale for each output range. For the scaling, settings of display value for 0% output and display value for 100% for each output range are required.

Output range	Output lower limit	Output upper limit	
DC0-10V	-1V	11V	
DC±10V	-11V	11V	
DC1-5V	0.6V	$5.4\mathrm{V}$	
DC0-20mA	0mA	22mA	
DC4-20mA	2.4mA	21.6mA	

In DC0-20mA output range, output lower limit is 0mA.

12-2. BCD OUTPUT FUNCTION

The models with a BCD output option can output a BCD output for a displayable value. BCD outputs are open-collector outputs which can be selected from NPN type or PNP type by model codes.


12-2-1. SOURCE DISPLAYABLE VALUE FOR OUTPUT

BCD output has one channel and an output source should be selected from various displayable items.

Even if the selected item is not displayed, the output is valid.

1 2 - 2 - 2. DATA OUTPUT

Data of selected source displayable value is output at the rate of sampling rate (10ms). The acquisition of the data should be done when the PC signal (BCD synchronized signal) is OFF. *By configuration, the output logic of BCD data signal and PC signal can be inverted.



12-2-3. ENABLE

By shorting the enable terminal to -D.COM or bringing to same voltage level, the BCD data and PC signal (BCD synchronous signal) output transistors become OFF.

1 2 - 3. RS-232C COMMUNICATION FUNCTION

The models with a RS-232C communication option can be acquired display data and set various configuration.

1 2 - 4. RS-485 (MODBUS RTU) COMMUNICATION FUNCTION

The models with a RS-485 communication option can be acquired display data and set various configuration.

13. ERROR MODE

13-1. DISPLAY ON OCCURRENCE OF AN ERROR

When some malfunctions occur, error codes are displayed according to the factor of the error.



1 3 – 2. LIST OF ERROR CODES AND RECOVERY PROCEDURES

When some malfunction occurs, an error code is displayed according to the factor of the error.

ERROR CODE	ERROR MESSAGE	RECOVERY PROCEDURE		
E000	Program sum error			
E006	RAM error			
E100 to 102	Errors associated with serial flash memory			
E103 to 105 E210 to 211	Errors associated with FRAM	During the error mode, hold down the ENTER key for 1 second (long-press) to		
E110 to 111	Error associated with sensor power short	reset or power down and on.		
E202 to 203	Errors associated with calibration values	*If the WPMZ does not recover by this procedure, please contact your dealer or our		
E204 to 205	Errors associated with setting values	company.		
E206 to 209	Errors associated with initial values			
Other than above codes	Other errors			

• If start-up delay is enabled, the WPMZ displays "-----" according to the delay time.

·If display value becomes out of displayable range, "OVER" is displayed in the display.

If error display is not recovered by system reset or power re-activation, please let us know the error code and situation.

During error mode, outputs are disabled.

14. SPECIFICATIONS

14-1. BASIC S	SPECIFICATIONS
Number of	: 1 or 2 (according to model codes)
measurement	
channel	
Display	: 2.4 inch TFT liquid crystal display
	Used in 1ch input : chA measurement result
	Used in 2ch inputs : chA measurement result,
	chB measurement result, calculation result, chA and chB measurement
	results, chA or chB measurement result and calculation result
Over warning	: By exceeding the range of display, displays OVER or -OVER
External controls	: 5 functions of the followings can be assigned to control terminals
	(user-configurable).
	①Comparative output reset function
	2 Measurement inhibit function: Measurement inhibit A/B/A&B
	③Current value hold function: Current value hold A/B/A&B
	(4) Maximum value hold function: Maximum value hold A/B/A&B
	⑤Minimum value hold function: Minimum value hold A/B/A&B
	©Pattern select function: Pattern select 1/2/3
	⑦Window select function
	®Trend Hold function
Ambient	: -5 to 50° C, 35 to 85%RH(Non condensing)
temperature	
range	$10 \pm 70^{\circ}$ C up to 00% PH
Storage temperature	: -10 to 70° C up to 60%RH
range	
Supply power	: AC power (WPMZ-5-1**-***)
	AC100 to $240V\pm10\%$ 50/60Hz
	DC power(WPMZ-5-3**-***)
	DC12V±10%
	DC power(WPMZ-5-4**-***)
	DC24 to 48V±10%
Power	: AC power (WPMZ-5-1**-**-**)
consumption	At AC100V:10VA max At AC240V:14VA max
	DC power(WPMZ-5-3**-***)
	At DC12V:6W max,
	DC power(WPMZ-5-4**-***)
	At DC24V:6W max, At DC48V:6.5W max
Sensor power	: Pulse input
	$DC12V \pm 10\%$ 100mA max, $DC24V \pm 10\%$ 50mA max.
	* For 2ch inputs of DC12*2 or DC24*2, allowable total current of both chA
	and chB is same as above.
	In the case of 2ch with combination of DC12V and DC24, allowable total
	power is 1.2W.
	Line driver input
	$DC5V \pm 10\%$ 200mA max
	* For 2ch inputs, allowable total current of both chA and chB is same as
	above.
External	: $96mm(W) \times 52mm(H) \times 145mm(D)$
dimension's	
Weight	: Approx. 350g
Withstand voltage	: AC power (WPMZ-5-1**-***)
	Between Power terminals and inputs/external controls/comparative
	outputs/other outputs AC3000V for 1 minute

		Graphical Digital Panel Meter WPMZ-5 INSTRUCTION MANUAL
		DC power (WPMZ-5-3or4**-**-**)
		Between Power terminals and inputs/external controls/comparative outputs/other outputs AC1500V for 1 minute
		AC power and DC power
		Between input terminals and external controls/comparative outputs/other outputs AC1500V for 1 minute
T 1		Between enclosures and each terminals AC3000V for 1 minute
Insulation resistance	:	Between terminals mentioned above, at DC500V 100M Ω or higher
Vibration	:	10 to 55Hz half amplitude 0.15mm in X,Y,Z directions for 30 minutes
tolerance		
Protective	:	IP66(front)
structure		
Installation environment	:	indoor use
Rated altitude	:	up to 2000m
Transient overvoltage	:	II
Measurement	:	II
category		
Pollution degree	:	2
Conformed EN	:	EN61326-1(EMS:industrial electromagnetic environment/EMI:Class A)
standard		(Applicable to line length only under 30m)
		EN61010-1
		EN50581
Material of enclosure	:	polycarbonate(PC) black UL94V-0

1 4 – 2. INPUT SPECIFICATIONS 1 4 - 2 - 1. PULSE INPUT

- Input specifications (common to chA,chB)

Frequency range	: 0.01Hz to 500kHz (*2ch input:250kHz)
Input signal	: Open collector (NPN/PNP), voltage pulse, totem pole output (complementary
	output), AC pulse, proximity sensor
Input method	: Single phase pulse
Input level	: Open collector
	Pullup to 12V or 24V
	Logic
	L level: $\leq 1.0V$
	H level: 3.9 to $30V$ (max. allowable voltage $\pm 50V$)
	Zero Cross
	AC60mV to 40V (max. allowable voltage 70V)
	*AC signal which gets across 0V.
Input resistance	: Open collector
	Pulled up to $12~{ m V}$ through approx. $10{ m k}\Omega$ (in the case of sensor power $12{ m V}$)
	Pulled up to $24~{ m V}$ through approx. $25{ m k}\Omega$ (in the case of sensor power $24{ m V}$)
	Pulled down to GND through approx. $10k\Omega$.
	Logic/Zero Cross
	Pulled down to GND through approx. $10 \mathrm{k}\Omega$
	2 wire
	Pulled down to GND through approx. 900 Ω
Input pulse width	: $\geq 0.9 \mu s$ (both of L level and H level)
	(2 channel inputs: $\geq 1.8 \ \mu s$)
Measurement method	: Cyclic calculation method
Display unit time	: Can be selected one of second, minute, hour
Accuracy	: $\pm (20 \text{ppm rdg} + 1 \text{digit}) @23 \pm 5^{\circ} \text{C}$

14-2-2. LINE DRIVER INPUT

- Input specification	s(co	mmon to chA,chB)			
Frequency range	:	0.01Hz to 500kHz (*2ch input:250kHz)			
Input signal	:	Differential input (line driver signal) * Can be connected to a device which has RS-422 compatible line driver output on one-on-one level.			
Input method	:	Single phase pulse			
Input sensitivity	:	\pm 1V or more (differential voltage)			
Input resistance	:	330Ω (terminate resistance)			
Maximum allowable voltage	:	$\pm 10 V$ (differential voltage)			
Input pulse width	:	$\geq 0.9 \mu s$ (both of L level and H level)			
		(2 channel inputs: $\geq 1.8 \ \mu s$)			
Measurement method	:	Cyclic calculation method			
Display unit time	:	Can be selected one of second, minute, hour			
Accuracy	:	\pm (20ppm rdg +1digit) @23 \pm 5°C			

1 4 – 3. OUTPUT SPECIFICATIONS [Comparative outputs]

Comparative output	ts】				
Open collector	:	Output rating			
output		NPN: sink current 50mA MAX.			
		PNP : source current 50mA MAX.			
		Applied voltage 30V MAX.			
		Output saturation voltage ≤1.2V at 50m	nA		
		Number of outputs 4 transistor output			
Relay output	:	Contact rating:AC250V 2A,DC30V 2A			
• •		Mechanical life:20 million times			
		Electrical life:100 thousand times or mo	ore		
		4 A contacts, AL1 and AL2, AL3 and AL	4 share common		
Control method	:	Microcomputer calculating method			
Judgement value	:	-999999 to 999999			
settable range	•				
Hysteresis		Settable within the range of 1-9999999 d	igits for each judgeme	nt value	
11,50010515	•	independently.	igito for cacil juagemen	it faide	
Comparison action	:	According to sampling rate (circulate pe	eriod)		
Setting condition	÷	Condition of comparison can be set to A		·1 . /	
Setting condition	•	•Level judgement mode		iy.	
		The alarm is ON when display value	exceeds judgement val	110	
		(over alarm)	exceeds judgement var	ac	
		The alarm is ON when display value	underruns judgement v	value	
		(under alarm)	underrans judgement	value	
		Over alarm (upper limit judgement)			
			Tee damage and mage 14		
		Condition of comparison	Judgement result AL1		
		display value>AL1 judgement value			
		display value>AL2 judgement value	AL2		
		display value>AL3 judgement value	AL3		
		display value>AL4 judgement value	AL4		
		Under alarm (under limit judgement)			
		Condition of comparison	Judgement result		
		AL1 judgement value>display value	AL1		
		AL2 judgement value>display value	AL2		
		AL3 judgement value>display value	AL3		
		AL4 judgement value>display value	AL4		
		•Zone judgement mode			
		The alarm is ON when display value	between upper and low	ver judgement	
		values (inside of zone alarm)	II.	, <u>,</u> , , , , , , , , , , , , , , , , ,	
		The alarm is ON when display value	out of upper and lower	iudgement	
		values (outside of zone alarm)	out of upper and to the	Jaagomono	
		Inside of zone alarm			
				Judgement	
		Condition of comparison		result	
		AL1 zone upper limit≥display value≥A	L1 zone lower limit	AL1	
		AL2 zone upper limit≥display value≥A		AL2	
		AL3 zone upper limit≥display value≥A		AL3	
		AL4 zone upper limit≥display value≥A		AL4	
		Outside of zone alarm			
		Condition of comparison		Judgement	
		-		result	
		display value>AL1 zone upper limit	د	AL1	
		or AL1 zone lower limit>display value display value>AL2 zone upper limit or AL2 zone lower limit>display value		AL2	
		or AL2 zone lower limit>display value	9	AL2	
		display value>AL3 zone upper limit or AL3 zone lower limit>display value		AL3	
		or AL5 zone lower limit>display value			
		display value>AL4 zone upper limit or AL4 zone lower limit>display value	2	AL4	
O .		1 0	<i>,</i>		
Comparison	:	8 pattern memory			

【Analog output】 Conversion method	:	D/A conversion method					
Resolution capability	:	Equivalent of 13bit					
Scaling	:	Digital scaling					
Output objective	:	An item can be selected from source displayable values					
Response speed	:	Up to 25ms	(0→90% re	esponse)			
Specifications for each output : Load resistance Accuracy (23±5° C 35 to 85%RH) Rip				Ripple			
		0 to 10V -10 to 10V 1 to 5V	$\geq 2 \mathrm{k} \Omega$	· (0.10/ CEG)	±50mVp-p		
		0 to 20mA 4 to 20mA	$\leq 550\Omega$	±(0.1% of FS)	±25mVp-p *Ripple for 4 to 20mA is at load resistance 250Q, 20mA output.		

【BCD output】		
Output type	:	Open collector output NPN/PNP type
Measurement data	:	Negative logic transistor is ON at logical "1"
Polarity signal	:	Negative logic transistor is ON at minus display
Over signal	:	Negative logic transistor is ON at over display
Synchronized signal (PC)	:	Transistor is ON for a fixed period every time data becomes valid.
Transistor output	:	Voltage 30V max. Current 10mA max.
capability		Output saturation voltage up to 1.2V at 10mA
Enable	:	By shorting the enable terminal to -D.COM or bringing to same voltage level, the BCD output transistors become OFF.

[RS-232C]		
Communication	:	$Modbus \hbox{-} RTU, Original Command, Original Output$
protocol		
Synchronization	:	Asynchronous
method		
Communication	:	Full duplex
method		
Baud rate	:	9600bps,19200bps,38400bps
Data length	:	7bit,8bit
Start bit	:	1bit
Parity bit	:	None, Odd, Even
Stop bit	:	1bit,2bit
Delimiter	:	CR LF,CR
Character code	:	Code ASCII
Transmission	:	No control sequence
control procedure		
Used signal names	:	TXD,RXD,SG
Number of	:	1
connectable units		
Cable length	:	Max. 15m
-		

[RS-485 Modbus]		
Communication protocol	:	Modbus RTU
Synchronization method	:	Asynchronous
Communication method	:	2-wire half- duplex
Baud rate	:	9600bps,19200bps,38400bps
Data length	:	8bit
Start bit	:	1bit
Parity bit	:	None, Odd, Even
Stop bit	:	1bit
Used signal names	:	Non-inverting (+), Inverting (-)
Number of connectable units	:	31
Cable length	:	Max.1.2km (total) *Conforming CE mark, less than 30m

15. TROUBLESHOOTING

No.	Condition	Checkpoint	Action
1	The display does not light up.	Check the power is supplied correctly.	 Check the supplied power meets requirement of supply power specifications. Using a circuit-tester, check voltage and wiring. Tighten up the screws of the terminals.
		Check the setting of "brightness" is set to "OFF".	 By pushing MENU and FUNC keys, if the display lights up, "BRIGHTNESS" is set to "OFF". Change "BRIGHTNESS" setting. *Refer to page 115.
			If the above procedure does not make an improvement, contact your dealer or our company.
2	Display keeps indicating"0" or"".	Check the input signal is applied adequately.	 Check the supplied input signal meets requirement of input specifications. Check input wiring and its continuity. Check with input diagnostic function of the product. Check status of external control function. Measurement inhibit Current value hold (see page 137) Check settings. Input filter setting (see page39) Instantaneous value auto zero setting (see page 46) Start delay time setting (see page 116) Initialize the WPMZ. Caution : All settings are reset to default values by the initialization.
		Check the selected display is appropriate for the input channel or displayed item in use.	 Using DISP key, try to switch display. Check setting of "Display Select". * "Display Select" setting (See page102)
			If phenomenon is not improved by above methods, please contact your dealer or our company.
3	OVER alarm display Error code display	Check setting of scaling.	•Review setting values. (see page 41, 53)
		Influence of noise	•Using shield cable, improving wiring. •Input filter setting(see page39)

No.	Condition	Checkpoint	Action
4	The display disappear, display value becomes over twice times.	Influence of spark noise from nearby electromagnetic stich, solenoid, electromagnetic valve, relay etc.	 Using shield cable, improving wiring. Input filter setting(see page39)
5	Two wire transmitters do not operate.	Two wire input of WPMZ is not applicable to 4-10mA current pulse.	
6	Comparative output does not turn OFF.	Check setting of "comparison judgement value" and "hysteresis".	 Setting of "comparison judgement value" (see page75) Check whether output mode of comparative output is set to "Latch". *Output mode(see page47)
7	Spend much time for display value changing to zero after input pulse stopping.	Consideration of "Instantaneous value auto zero".	• Setting of "Instantaneous value auto zero" (see page46)
8	Fluctuations of displayed value are wide.	(Sometimes, displayed value becomes small.)	 Check the level of input signal is under nominal value. Input filter setting (see page39)
		(Sometimes, displayed value becomes large.)	•Input filter setting (see page39)
		(Input signal varies in actually.)	 Consideration of "Average" functions. *Instantaneous Value Moving Average (see page48) *3 Instantaneous Value Simple Average (see page48)
9	Analog output abnormal	Check by "test output"	•Check using "test output" function.
		Check connected load is suitable.	•Disconnect the load and check the output value.
		Check wiring.	• Check whether the load is connected to suitable terminal (current output or voltage output).
		Check settings.	 Check scaling setting for analog output. Check selected displayable value for analog output. Check output range of analog output. If phenomenon is not improved by
			above methods, please contact your dealer or our company.
10	BCD output abnormal	Check connected device is suitable. (NPN/PNP, external pullup etc.) Check output logic setting is correct.	•Check using "test output" function.

No.	Condition	Checkpoint	Action
11	RS-232C communication abnormal	Check wiring, wire length are correct. Check setting such as baud rate is correct. Check communication command is correct.	• Check using "test output" function.
12	RS-485 communication abnormal	Check wiring, wire length, termination, number of connected devices are correct. Check setting such as baud rate is correct.	• Check using "test output" function.

16. APPENDIX

16-1. KEY OPERATION REFERENCE CHART

The functions of keys are shown in the chart below.

Opera	Operation in "measurement mode"									
FUNC	MENU	DISP	ENTER	\approx	\otimes	≪	≫	Action		
0								Moves to entering short-cut function of external control.		
	0							Moves to setting mode.		
		0						Switches measurement display contents.		
			0					Resets the system by 1sec. long-pressing in error mode. condition		
				0						
					0			When assigned short-cut functions, makes the		
						0		function ON/OFF by long-pressing.		
							0			
		0	0					Makes the key lock function ON/OFF by long-pressing simultaneously.		

Operat	Operation in "setting mode"									
FUNC	MENU	DISP	ENTER		\mathbf{i}	≪	≫	Action		
0								Moves from shortcut function entry display to measurement mode		
	0							Stores settings and moves to measurement mode.		
		0						No action		
			0					Fixes setting parameters.		
				\bigcirc						
					\bigcirc			Moves to other setting displays / Moves cursors		
						\bigcirc		in setting displays / Modifying setting values.		
							0			

*Note: \bigcirc short-pressing \bigcirc long-pressing (holding down more than 1sec.)

16-2. SETTING VARIABLES

		3rd Layer (S	Setting Variables)	4th Lay	er (Setting Values)		
1st Layer (Large Categories)	2nd Layer (Small Categories)	Name of Variables	Character Strings on Display (Abbreviated Form)	Initial values	Settable Variables	Remarks	
		Pattern select	PatternSelect	Pattern1(or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern8	Select pattern No. to set.	
	∃ B	Input Type	InputType	OpenCollector	OpenCollector/ Logic/ ZeroCross/ 2Wire	Select input signal type	
	Pulse input B PulseInputB]	Input Filter	InputFilter	None	None/ 30Hz/ 1.5kHz/ 15kHz	Select input analog filters	
	lse ir lseIn	Sensor Power	SensorPower	12V	12V/24V	Switch Sensor power voltage	
	Pulse input A, Pu [PulseInputA, Pu	Instantaneous Value Display Coefficient	InsDispCoef	1.00000×10 ⁰	0.00000 to 9.999999×10 ^{.9~9}	For scaling setting of instantaneous value display, multiply frequency by	
	se ing lseIn	Instantaneous Unit Time	InsUnitTime	Sec	Sec/ Min/ Hour	instantaneous coefficient and unit time.	
	Puls [Pu	Instantaneous Value Decimal Point Position	InsDecPoint	####### (No decimal point)	######################################	Set number of digits after decimal point	
		Instantaneous Value Display Unit	InsDispUnit	None	None/ select from 62 units (See 6-2)/custom unit	Refer to detailed instruction manual about custom unit	
	0	Instantaneous Value Auto Zero	InsAutoZero	0.00	0.00 to 99.99sec	Displays 0 if no pulse input over more than setting time	
	[WPMZ-5-*P*] (Generic pulse input)	Instantaneous Value Moving Average	InsMoveAve	None	None/ 2times/ 3times / 4times/ 5times/ 6times/ 7times/ 8times/ 9times	Set number of moving average.	
	[WPMZ-5-*P*] eneric pulse inp	Instantaneous Value Simple Average	InsSimpleAve	None	None/ 2 times/ 4 times/ 8times/ 16times/ 32times/ 64times/ 128times/ 256 times	Set number of simple average for internal sampling (10ms)	
ut	D)	Instantaneous Value Display Step	InsDispStep	None	None/ 5steps/ 10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)	
1. Input		Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
		Input Type	InputType	LineDriver	LineDriver	Line Driver only	
	input B nputB]	Input Filter	InputFilter	None	None	No input analog filter	
	qui e Inp	Sensor Power	SensorPower	$5\mathrm{V}$	5V	5V only	
	Pulse input A, Pulse input B [PulseInputA, PulseInputB]	Instantaneous Value Display Coefficient	InsDispCoef	1.00000×10 ⁰	0.00000 to 9.99999×10 ^{-9~9}	For scaling setting of instantaneous value display, multiply frequency by instantaneous coefficient and	
	Pulse i [Pulse]	Instantaneous Unit Time	InsUnitTime	Sec	Sec/Min/Hour	unit time.	
	[Instantaneous Value Decimal Point Position	InsDecPoint	####### (No decimal point)	######################################	Set number of digits after decimal point	
		Instantaneous Value Display Unit	InsDispUnit	None	None/select from 62 units (See 6-2)/custom unit	Refer to detailed instruction manual about custom unit	
		Instantaneous Value Auto Zero	InsAutoZero	0.00	0.00 to 99.99sec	Displays 0 if no pulse input over more than setting time	
	5-*L*] r input)	Instantaneous Value Moving Average	InsMoveAve	None	None/ 2times/ 3times / 4times/ 5times/ 6times/ 7times/ 8times/ 9times	Set number of moving average.	
	[WPMZ-5-*L*] (Line driver input)	Instantaneous Value Simple Average	InsSimpleAve	None	None/ 2 times/ 4 times/ 8times/ 16times/ 32times/ 64times/ 128times/ 256 times	Set number of simple average for internal sampling (10ms)	
	(T)	Instantaneous Value Display Step	InsDispStep	None	None/ 5steps/ 10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)	

ries)	er çories)	3rd Layer (§	Setting Variables)	4th Lay	ver (Setting Values)		
1st Layer (Large Categories)	2nd Layer (Small Categories)	Name of Variables	Character Strings on Display (Abbreviated Form)	Initial values	Settable Variables	Remarks	
		Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
	ulation alc]	Expression for instantaneous value	InsExpression	None	None/ (B/A)*100 / (B/A-1)*100 /B-A / (B/(A+B))*100 / A+B	Select expression for calculation of instantaneous value.	
	2 Input Calculation [2InputCalc]	Instantaneous value decimal point position	InsDecPoint	####### (No decimal point)	######### / ####### # / ##### ### / ####.#### / ###.##### / #.######	Set number of digits after decimal point	
ıt	2 In [Instantaneous value display unit	InsDispUnit	None	None/select from 62 units (See 6-2)/custom unit	Refer to detailed instruction manual about custom unit	
1. Input		Instantaneous value display step	InsDispStep	None	None/5steps/10steps	Setting of steps of display (If set to 5steps, displayed only 0 or 5 on LSB)	
	External Control [ExternalCtr1]	Function of external control terminal 1 to 5	ExtCtrl1Func ExtCtrl2Func ExtCtrl3Func ExtCtrl4Func ExtCtrl5Func	None	None/ CompareReset/ MeasureBlockA/ MeasureBlockB/ MeasureBlockA&B/ DispHoldA/ DispHoldB/ DispHoldA&B/ MaxHoldA/ MaxHoldB/ MaxHoldA&B/ MinHoldA&B/ PatternChange1/ PatternChange2/ PatternChange3/ MonitorChange/ TrendHold	Select functions assigned to external control terminals.	
	• Output	Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
	ıparative	Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select source output display value to compare.	
	L3/ Com L4l	Compare mode	CompareMode	LevelJudge	LevelJudge/ ZoneJudge	Select compare mode	
	utput AL3. mnareAL4	butput A mpareA		OnConditions	Excess	Excess/LessThan	In level judge mode
	ttive C L3/ Co			InTheZone	InTheZone/OutsideTheZone	In zone judge mode	
	mpara areAl	Comparison		10000 0	Threshold:±9999999 Hysteresis:0 to 999999	In level judge mode	
2.Output	AL2/ Co AL4 L2/ Comr	judgement value	Threshold	0 10000 0	Zone lower limit:±999999 Zone upper limit :±999999 Hysteresis:0 to 999999	In zone judge mode	
2.	ALJ/ Comparative Output AL2/ Comparative Ou AL4 CompareALJ/ CompareAL2/ CompareAL3/ Com	Comparison ON delay	OnDelay	None	None/20ms/50ms/100ms/	Comparative output turns ON, if ON condition continues over set delay time.	
	nparativ eAL1/ Co	Comparison OFF delay	OffDelay	None	200ms/500ms/1s/5s/10s/20s	Comparative output turns OFF, if OFF condition continues over set delay time.	
	Comparative Output AL1/ Comparative Output AL2/ Comparative Output AL3/ Comparative Output AL4 [CompareAL1/ CompareAL2/ CompareAL3/ CompareAL4]	Output mode	OutputMode	Normal	Normal/Latch/OneShot5ms/ OneShot 10ms/ OneShot 20ms/ OneShot 50ms/ OneShot 0.1s/ OneShot 0.2s/ OneShot 0.5s/ OneShot 1s/ OneShot 2s	Select output mode of comparison	
	barative	Output logic	OutputLogic	Negative (NO)	Positive(NC)/Negative(NO)	NC/NO are for relay output product.	
	ComF	Background Color at ON	OnBgColors	Black	Black/Red/Yellow/Green	Background color priority AL1>AL2>AL3>AL4	

hries)	r iries)	3rd Layer (S	Setting Variables)	4th Lay	ver (Setting Values)		
1st Layer (Large Categories)	2nd Layer (Small Categories)	Name of Variables	Character Strings on Display (Abbreviated Form)	Initial values	Settable Variables	Remarks	
		Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
	ttput tput]	Output range	OutputRange	0-10V	0-10V/±10V/1-5V/0-20mA/ 4-20mA	Select output range (type).	
	Analog Output [AnalogOutput]	Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select a displayable item for analog output	
		Output scale	OutputScale	0 10000	0% display value :±999999 (±99999) 100% display value : ±999999(±99999)	Set scaling for analog output. Set expected display values at 0% and 100% output.	
	at at]	Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
ut	BCD Output [BCD Output]	Source output display value	OutputDispValue	None	None/InsA/InsB/InsCalc	Select a displayable item for BCD output	
2.Output	BCD [BCD	Data signal logic	DataSignalLogic	Negative	Positive /Negative	Select logic of data signal output.	
2		Synchronous signal logic	SyncSignalLogic	Negative	Positive /Negative	Select logic of synchronous signal (PC) output.	
	RS-485 Modbus communication [ModbusCom]	Slave Address	SlaveAddress	1	1/2/3/4/ /30/31	Set ID number.	
		Baud rate	Baudrate	19200bps	9600bps/19200bps/38400bps	Set baud rate.	
	RS-4 com1 [Mo	Parity	Parity	Even	None/Even/Odd	Set parity bit.	
		Protocol	Protocol	Modbus-RTU	Modbus-RTU/OriginalComm and/OriginalOutput	Set protocol	
	C ation XOM]	Baud rate	Baudrate	19200bps	9600bps/19200bps/38400bps	Set baud rate.	
	RS-232C nmunicat -232C CC	Data length	DataLength	7bit	7bit/8bit	Set data character length	
	RS-232C communication RS-232C COM	RS-232C communication [RS-232C COM]	Parity	Parity	Even	None/Even/Odd	Set parity bit.
	CC B	Stop bit	Stopbit	1bit	1bit/2bit	Set stop bit length.	
		Delimiter	Delimiter	CR LF	CR/CR LF	Set delimiter type.	
	ect E]	Measure select	MeasureSelect	1. Input: InsA 2inputs: InsA+InsB	InsA/InsB/InsCalc/ InsA+InsB / InsCalc+A+B/ InsA+Comp/InsB+Comp/Ins Calc+Comp	Select displayable items can be switched by DISP key or external control for numerical value display. (multiple selects are available)	
	Display Select [DispSelect]	Level select	LevelSelect	1. Input: InsA 2inputs: InsA+InsB	InsA/InsB/InsCalc/	Select displayable items can be switched by DISP key or external control for level display. (multiple selects are available)	
3. Display	Ι	Trend select	TrendSelect	1. Input: InsA 2inputs: InsA+InsB	InsA+InsB	Select displayable items can be switched by DISP key or external control for trend display. (multiple selects are available)	
3. Di	<i>v</i>	Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
	Level Display [LevelDisp]	Instantaneous value A scale	InsA Scale				
	Level [Leve	Instantaneous value B scale	InsB Scale	0 10000	Lower limit:±9999999 Upper limit:±9999999	Set display scale of level display. Left edge of display is lower limit and right edge of display is	
		Instantaneous calculation scale	InsCalcScale			higher limit	

()	(s	3rd Layer (\$	Setting Variables)	4th Lay	rer (Setting Values)		
1st Layer (Large Categories)	2nd Layer (Small Categories)	Name of Variables Character String on Display (Abbreviated For		Initial values	Settable Variables	Remarks	
		Pattern Select	PatternSelect	Pattern1 (or pattern No. in use)	Pattern1/ Pattern2/ Pattern3/ Pattern4/ Pattern5/ Pattern6/ Pattern7/ Pattern 8	Select pattern No. to set.	
ay	play isp]	Instantaneous value A scale	InsA Scale			Set divelop and a fitneral	
3. Display	Trend Display [TrendDisp]	Instantaneous value B scale	InsB Scale	0 10000	Lower limit :±999999 (±99999) Upper limit :±999999	Set display scale of trend display. Bottom edge of display is lower limit and top edge of display is	
	L	Instantaneous calculation scale	InsCalcScale		(±99999)	higher limit.	
		Time axis	TimeAxis	1s/div	1s/div,2s/div,5s/div,10s/div,30 s/div,60s/div,120s/div	Select time for 1 division of time axis.	
		Brightness	Brightness	5 Bright	5 Bright/4/3/2/1 Dark/0 Off	Select brightness of display. *"0 Off" is set, whole display is black out	
			Power on delay	PowerOnDelay	None	None/2sec/5sec/10sec/20sec /30sec/60sec	Select time from power on to starting measurement
				Power saving time	PowerSavingTime	None	None/1min/2 min/5 min/10 min/30 min/60 min
	. —	Language	Language	Japanese	Japanese /English	Select language	
	General [Gerenal]	Direction of display	DisplayDirection	Horizontal	Horizontal/Vertical	Select direction of display	
tem	Gei [Gei	Setting protect	SettingProtect	Disable	Disable/Enable	If ON, changing settings are disabled.	
4.System		Pattern Copy	PatternCopy	Pattern1 (Copy From) PatternAll (Copy To) Execute (OperationSele ct)	Pattern1/2/3/4/5/6/7/8 Pattern1/2/3/4/5/6/7/8/Pat ternAll	Function of copying settings for each pattern.	
	e]	Save user defaults	UserDefaultSave	Message "Save curr values?"	ent settings as user initial		
	Initialize [Initialize]	Initialize to user defaults	UserDefaultLoad		setting values to user initial		
	In [In	Initialize to factory default	FactoryDefaultLoad	Message "Initialize default?"	setting values to factory		

1st Layer (Large Categories)	2nd Layer (Small Categories)	3rd Layer (Setting Variables)		4th Layer (Setting Values)		
		Name of Variables	Character Strings on Display (Abbreviated Form)	Initial values	Settable Variables	Remarks
5.Diagnosis	Input Diagnosis [ImmtDiaø]	Pulse input A Pulse input B	PulseInputA PulseInputB	_	-	Check for input signal existence. (Displays pulse counts)
		External control inputs	ExternalCtrl	_	_	Check for ON/OFF state of terminals
	Output Test (Simulated output) [OutputTest]	Comparative output AL1 to AL4	CompareAL1 CompareAL2 CompareAL3 CompareAL4	_	_	Outputs ON level or OFF level
		Analog output	AnalogOutput	-	_	Outputs level of 10% steps of rating.
		BCD Output(Data) BCD Output(PC)	BCD Output(Data) BCD Output(PC)	_	_	Outputs ON level or OFF level for each bit
		Modbus Communicatio n RS-485	ModbusCom	_	_	Displays receive data and transmit data
		RS-232C	RS-232C Com	_	_	Displays receive data and transmit data

Graphical Digital Panel Meter WPMZ-5 INSTRUCTION MANUAL

The contents of this instruction manual are subject to change without prior notice.

watanabe

WATANABE ELECTRIC INDUSTRY CO.,LTD. http://www.watanabe-electric.co.jp/en/

6-16-19, JINGUMAE, SHIBUYA-KU, TOKYO 150-0001, JAPAN TEL +81-3-3400-6147 FAX +81-3-3409-3156